

SATION KNX

SATION-PM1423

Fan Coil Room Thermostat
Product Manual

	Page
1 General.....	3
1.1 Overview of Product and Functions	4
2 Technology.....	5
2.1 Technical data.....	5
2.2 Connection diagram.....	7
2.3 Dimensional drawing.....	7
2.4 Assembly and installation.....	8
2.5 Operation and display	11
3 Commissioning.....	12
3.1 Application program for the ambient temperature controller.....	12
3.2 Parameters.....	13
3.2.1 Parameter window "General"	13
3.2.2 "Temperature Measurement" parameter window.....	17
3.2.3 Parameter window "Controller general"	20
3.2.4 Parameter window "Controller heating"	24
3.2.5 Parameter window "Controller PWM heating"	29
3.2.6 Parameter window "Controller cooling"	31
3.2.7 Parameter window "Controller PWM cooling"	36
3.2.8 Parameter window "Additional heating stage"	38
3.2.9 Parameter window "Additional cooling stage"	40
3.2.10 Parameter window "Setpoint general"	42
3.2.11 Parameter window "Setpoint manual"	45
3.2.12 Parameter window "Setpoint heating / cooling".....	48
3.2.13 Parameter window "Fan Coil general"	53
3.2.14 Parameter window "Fan Coil heating"	56
3.2.15 Parameter window "Fan Coil cooling"	59
3.2.16 Parameter window "Compensation"	62
3.2.17 Parameter window "Valve Heating – 3-position"	66
3.2.18 Parameter window "Valve Heating – 2-position, PWM "	69
3.2.19 Parameter window "Buttons for Switching Group"	71
3.3 Communication objects.....	73
3.3.1 General	73
3.3.2 Control system	74
3.3.3 Setpoints	77
3.3.4 Control value	79
3.3.5 Heating / cooling	80
3.3.6 Fan automatic / manual.....	81
3.3.7 Monitoring	83
3.3.8 Temperature alarm	84
3.3.9 Status byte	85
3.3.10 Compensation.....	86
3.3.11 Fan stage - state	87
3.3.12 Valve Heating / cooling	88
3.3.13 Function Buttons.....	89
3.4 Special operating states.....	89

4	Planning and use	90
4.1	Operating modes.....	90
4.1.1	Operating mode switching 1 bit	91
4.1.2	Operating mode switching 1 byte	91
4.2	Temperature measurement.....	93
4.2.1	Internal temperature recording.....	93
4.2.2	External temperature recording.....	93
4.2.3	Monitoring	93
4.2.4	Adjustment	94
4.3	Controller.....	95
4.3.1	2-point controller	96
4.3.2	Continuous controller	97
4.3.3	PWM controller	98
4.3.4	Fan Coil.....	99
4.3.5	Control parameters with PWM and continuous controller (fan coil) ...	99
4.3.6	Two-stage heating and cooling	100
4.4	Setpoints	101
4.4.1	Dependent setpoints	101
4.4.2	Individual setpoints.....	102
4.4.3	Minimum distance	103
4.5	Fan Coil general.....	104
4.6	Compensation.....	106
4.6.1	Summer compensation	106
4.6.2	Winter compensation	107

1 General

The Fan Coil room temperature controller with display is a continuous KNX room temperature controller for fan convectors in 2 and 4-pipe systems. It measures the current room temperature (actual value) and sends a continuous manipulated variable (0 - 100%) to a fan coil actuator to maintain the desired room temperature. The device operates in both heating and cooling mode.

Hotel management systems can directly access the Fan Coil room temperature controller with display via KNX and trigger controllers in the room. The fan speed can also be selected manually with buttons (forced operation). This makes it possible to adjust the hotel room temperature as required by the customer or guest.

The device can be linked to the functions of the master room controller and fan coil actuator via the KNX.

This manual contains detailed information on the Fan Coil room temperature controller with display, its installation and programming. The operation of the device is explained using examples.

The manual is divided into the following sections:

- Section 1 General
- Section 2 Technology
- Section 3 Commissioning
- Section 4 Planning and Application
- Section A Appendix

1.1 Overview of Product and Functions

The Fan Coil ambient temperature controller with display records the current room temperature and controls the heating and/or cooling. It also controls 2 and 4-pipe Fan Coil units and conventional air-conditioners.

The display is backlighted for easier reading.

The device supports all functions for international hotel applications. It can operate with the following operating modes: heating/cooling, heating only and cooling only.

The ambient temperature controller is fitted with push-switches and an LC display to show the current operating modes and values. The ambient temperature controller is very easy and intuitive to operate with the use of international symbols on the push-switches and in the display. The device has five push-switches and one Buttons Group:

- ON/OFF, comfort/standby switch
- Temperature up
- Temperature down
- Fan stage adjustment
- Switch mode
- Buttons for Switching Group

The sensor is a surface-mounted device and does not require a cover frame. A bus terminal is included for connection to the KNX. A separate bus coupling unit is not required. The Fan Coil room temperature controller with display does require an auxiliary power supply.

Note
The pictures of the parameter window in this manual correspond to the ETS 5 parameter windows.

2 Technology

The Fan Coil ambient temperature controller with display records the current room temperature and controls the heating and/or cooling. It also controls 2 and 4-pipe Fan Coil units and conventional air-conditioners.

A bus terminal is included for connection to the KNX. A separate bus coupling unit is not required.

The ambient temperature controller is fitted with push-switches and an LC display to show the current operating modes and values.


2.1 Technical data

Power supply	- Bus voltage	21...30 V DC over the bus
	- Current consumption	Type. 10 mA
	- Auxiliary power	21...30 V DC
Connections	- KNX	Bus terminal
	- Temperature sensors	Accuracy of temperature sensor +/- 0.3 K (can be calibrated by parameters) Sensor type: IC
Control and display elements	- LCD display	The LCD can be lighted if required. Use the "Lighting Display" parameter. This allows the LCD lighting to be always on or always off, or to be lighted after pushing a switch and remain on for 5 seconds.
	- "ON/OFF" put-switch [ON/OFF comfort/standby optional]	If freezing protection is not activated: ambient temperature control is switched to freezing protection. "OFF" shown on display. If freezing protection is activated: ambient temperature control operates in the mode that it would have had without being switched off. If the optional ON/Off comfort/standby operating mode is selected, the device switches between comfort and standby when a push-switch is pressed briefly, and switches OFF if the switch is pressed for a longer period (> 2s).
	- "Temperature up" push-switch	In night mode the settemperature can be manipulated till the next change of operating mode happens. When a push-switch is pressed, the set temperature is changed by a configurable value (0.1K / 0.2K / 0.5K / 1K). The display is switched to "Set Temperature". The actual temperature is displayed again 5 seconds after the last push-switch actuation, if this has been configured. If the optional mode "Enable extended button press for switching heating/cooling set value" is enabled, the device switches to the heating set value when the switch is pressed and held (2s).
	- "Temperature down" push-switch	When a push-switch is pressed, the set temperature is changed by a configurable value (0.1K / 0.2K / 0.5K / 1K). The display is switched to "Set Temperature". The actual temperature is displayed again 5 seconds after the last push-switch actuation, if this has been configured. If the optional mode "Enable extended switch press for switching heating/cooling set value" is enabled, the device switches to the heating set value when the switch is pressed and held (2s).

	<ul style="list-style-type: none"> - "fan stage adjustment" - mode switching - "function button top / bottom" 	<p>When the switch is pressed, the device runs through the sequence "1 2 3 Auto 0 1 ..." starting from the current fan stage. If the fan is set to automatic, this is deactivated when the switch is first pressed and the next fan stage is activated- This push-switch switches the mode,when the icon is flashes,you can set the corresponding parameters</p> <p>Switch: Toggle ON/OFF with 1 button or ON/OFF with 2 buttons ; Dimming:ON/OFF with a short pulse (< 0.5 s); Brighter / darker with a long pulse (> 1 s); Blind: A long pulse (>1 s) starts the up/down motor; A short pulse (<0.5 s) stops the motor or slightly adjusts the position of blinds; Scene: A short pulse (<0.5 s) starts the scene. A long pulse (>5 s) saves the actual position of all actuators involved as adjusted previously;</p>	
Protection	- IP 20	Acc. to DIN EN 60529	
Protection class	- III	Acc. to DIN EN 61140	
Insulation category	<ul style="list-style-type: none"> - overvoltage category III - pollution severity 2 	Acc. to DIN EN 60664-1 Acc. to DIN EN 60664-1	
Temperature range	<ul style="list-style-type: none"> - Use - Storage - Transport 	- 5°C...+45°C -25°C...+55°C -25°C...+70°C	
Ambient condition	<ul style="list-style-type: none"> - maximum relative humidity - Maximum air pressure 	93% non-condensing equivalent to 2000 m	
Type, case, design	<ul style="list-style-type: none"> - AP device with integrated bus coupler (no additional supply voltage) - Dimensions HxWxD - Colour - Device labels - Fire classification V0 - RoHS-compliant and halogen-free 	Case: 81x81x20 mm Display: 51x39 mm white, aluminium-silver function symbols on the case - ON/OFF - fan switching - temperature up - temperature down - mode switching	
Installation	<ul style="list-style-type: none"> - monoblock device, bus connection - surface-mounted installation with holder (design part) 		
Licence	- KNX acc. to EN 50 090-1, -2		
CE marking	- acc. to EMC and Low-Voltage Directives		
Application program	Quantity	Max. quantity	Max. quantity
	Communication objects	Group addresses	Allocations
Fan Coil displays controls adjustments/1.2	47	254	255


Note ETS 4 or higher is required for programming.
The application program is in ETS 4 at SATION/Heating, Air-conditioning, Ventilation/Thermostat.

2.2 Connection diagram



Connection diagram of Fan Coil ambient temperature controller with display

2.3 Dimensional drawing







Dimensional drawing of Fan Coil ambient temperature controller with display

2.4 Assembly and installation

The Fan Coil with display ambient temperature controller is a surface-mounted device (AP) with an integrated bus coupler. The device operates without additional supply voltage. It can be installed on flush-mounted sockets (UP) (VDE, China, British Standard).

Selection of a suitable installation location for the controller and suitable parameter settings are essential for good temperature detection.


- The ambient temperature controller should be installed approximately 150 cm above the floor and 50 cm from the door frame.
- The ambient temperature controller should be installed on a wall opposite the radiator.
- The radiator and the ambient temperature controller must not be separated by corners in the room.
- An ambient temperature controller should not be installed near a radiator or behind curtains.
- It should also not be installed on an exterior wall - low outside temperatures will influence the temperature regulation.



- The ambient temperature controller must not be exposed to direct contact with liquids.



- Temperature regulation will also be affected by exposure to heat from electrical appliances and direct sunlight on the ambient temperature controller.



Requirements for commissioning

A PC with ETS (ETS 4 or higher) and a connection to the KNX bus, e.g. over a KNX interface, is required to commission the device.

The device is ready for operation once it is connected to the bus voltage. Auxiliary voltage is not required.

The device must be installed and commissioned by a qualified electrician only. The relevant standards, directives, regulations and requirements for planning and installation of electrical systems must be observed.

- The device must be protected from moisture, dirt and damage during transport, storage and operation.
- The device must be operated in accordance with the specified technical data only.

Assigning the physical address

The physical address, group address and parameters are assigned in the ETS.

Cleaning


The device can be cleaned with a dry cloth if it is dirty. If this is not sufficient, use a cloth lightly moistened with a detergent solution. Never use aggressive cleaners or solvents.

Maintenance

The device is maintenance-free. It must not be repaired by third parties if it is damaged, such as in transport and/or storage. The guarantee is cancelled if the device is opened.

The device must be accessible at all times for operation, testing, inspection, maintenance and repair (acc. to DIN VDE 0100-520).

2.5 Operation and display



Depending on the configuration done with ETS, the connections and the availability of information (local or received from the bus), the series of symbols allow to display:

1. room actual temperature (it may be the temperature calculated using a weighted average of two values);
2. relative humidity (in %);
3. Air quality (reserved);
4. fan status (1-2-3-automatic-off) and operation mode(AUTO/MANU), when present;
5. Digital display;
6. Relative Humidity Unit %;
7. Temperature in degrees Fahrenheit (° F) / Celsius (° C);
8. Setting;
9. Timing;
10. Ventilation mode;
11. Cooling mode;
12. Air conditioning heating mode;
13. Floor heating mode;

Symbols that can be activated on the LC-display:

		Digits (for numeric values display) , Alphabet (for the fault code display)	
	Celsius degrees		Indoor temperature
	Fahrenheit degrees		Relative humidity
	Percentage (relative humidity)		Reserved, not activated
	Cooling mode active (device calling or setpoint not reached)		Heating mode active (device calling or setpoint not reached)
	Cooling mode active (device not calling or setpoint reached)		Heating mode active (device not calling or setpoint reached)
	ventilation mode active, fan operates for the preset stage		Floor Heating or other heating mode active (device calling or setpoint not reached)
	ventilation mode active, device not calling fan stage control		Floor Heating or other heating mode active (device calling or setpoint not reached)
	OFF (fan-coil switched off)		SET
	Automatic fan-coil operation (example: speed 3)		Timed shutdown
	Manual fan-coil operation (example: speed 2)		

Messages

Internal Temp error	IA	– Fault in internal temperature sensor
External Temp error	EA	– Update of external temperature not received ->
Outdoor Temp error	OA	– Update of outside temperature not received ->
Actuator error	AA	– Update of actuator not received ->
Dewpoint	dP	– Dewpoint alarm
Condensate alarm	CA	– Condensate collector alarm

Heating setpoint adjustment: Display of SET and heating symbol
Cooling setpoint adjustment: Display of SET and cooling symbol

If the actual temperature is permanently displayed (standard), the set temperature is displayed by the symbol "SET".

3 Commissioning

3.1 Application program for the ambient temperature controller

The Fan Coil Display Operate Control/1.2 application program for the Fan Coil room temperature controller with display controls the device for heating, cooling or heating and cooling. The ETS shows different parameters and communication objects depending in the functions selected in the "Control Function in Use" parameter.

A "2-point control", a "PWM control", a "Continuous control" or a "Fan Coil Actuation" can be implemented for heating and/or cooling in all controller functions. A supplementary stage for heating and also for cooling can also be actuated.

A temperature value can also be received by an additional temperature sensor via the KNX for improved temperature control in larger rooms. The measured value is then applied to the room temperature control with a defined weighting.

The room temperature controller can be operated with dependent or individual setpoints. Dependent setpoints mean that the setpoints in standby and night mode are always based on the basic setpoint, and with individual setpoints a separate setpoint can be set for every operating mode. (See also page 101 in Section 4.4 Setpoints at Planning and Application.)

3.2 Parameters

3.2.1 Parameter window "General"

General		
Temperature measurement	Send "In operation" object	No
Controller general	Display selection temperature °C/°F or humidity %	Only temperature °C
Heating control	Display during normal operation	Absolute setpoint temperature
Cooling control	Display in adjusting mode	☒ Absolute setpoint temperature ☐ Relative setpoint temperature (+/-K)
Setpoint general	Display heat/cool is active	☐ If operating mode is active ☒ When requesting heating or cooling
Manual setpoint	Display illumination	5 seconds recovery time
Setpoints heat/cool	Operating mode switchover	☐ 1 Bit (3 x DPT_Switch) ☒ 1 Byte (2 x DPT_HVAC mode)
FanCoil general	Enable switchover of comfort/standby via button On/Off	☐ Yes ☒ No
FanCoil heating	Operation mode after reset	Comfort operation
FanCoil cooling		

Send "In operation" object

Options:

- No
- Send value "0" cyclic
- Send value "1" cyclic

The "In operation" object reports to the bus that the device is operating correctly. This periodic message can be monitored by an external device. The following parameters are shown:

transmission period in s [1...65.535]

Options: - 1...60...65.535

The period at which the "In operation" object sends a message periodically is set here.

Enable switchover of temperature display via button °C/°F

Options:

- Yes, standard °C
- Yes, standard °F
- No, standard °C
- No, standard °F

This parameter enables the °C/°F push-switch. The user can then switch the temperature display from °C to °F. The temperature is always converted from °C to °F in the Fan Coil ambient temperature controller with display, because only °C values can be sent to the KNX.

If the "No" setting has been made, the °C/°F push-switch has no function and the user cannot change the display.

Display during normal operation

- Options:
- No temperature display
 - **Absolute setpoint temperature**
 - Relative setpoint temperature (+/-K)
 - Current setpoint

Use this parameter to specify what information is displayed in the temperature sensor mode. The current temperature, the current setpoint, the relative current setpoint (adjustable setpoint) or no temperature can be displayed.

Display in adjusting mode

- Options:
- **Absolute setpoint temperature**
 - Relative setpoint temperature (+/-K)

Use this parameter to specify what information is displayed in the adjustment mode. The setpoint temperature or the relative current setpoint (adjusted setpoint) can be displayed.

Display heat/cool is active

- Options:
- If operating mode is active
 - **When requesting heating or cooling**

The heat/cool parameter shows the configuration either for "When requesting heating or cooling" or "If operating mode is active". The initial setting shows only heat or cool, if the system is actually heating or cooling.

Display illumination

- Options:
- Always On
 - Always Off
 - **15 seconds recovery time**

Use this parameter to set the LCD backlighting. It can be on at all times, off at all times, or it switches off automatically 15 s after an actuation.

Note:

If the 1-bit communication object "lighting" receives an On message, the backlighting remains on until an Off message is received.

Operating mode switchover

- Options:
- 1 Bit (3 x DPT_Switch)
 - **1 Byte (2 x DPT_HVACmode)**

Switching operating mode defines whether the ambient temperature controller has three 1-bit communication objects, "Comfort/Standby", "Night Mode" or "Freezing/Heat Protection", or two 1-byte communication objects for switching operating mode.

If an ON message is received by the Comfort/Standby object in 1-bit switching operating mode, the Comfort operating mode is activated. If an OFF message is received Standby mode is activated. If an ON message is received by the Night Mode object, night operating mode is activated. An OFF message deactivates Night Mode. Freezing/Heat Protection mode is also activated with an ON message and deactivated with an OFF message.

If an ON message is received by multiple objects, Freezing/Heat Protection has a higher priority than Comfort Mode. Night reduction has a higher priority than Comfort Mode.

When switching operating mode via 1 byte two 1-byte communication objects are available.

Note: the two 1-byte communication objects have different behaviour when receiving a message. One object evaluates received messages "normally". This means, for example, if a comfort telegram is received, the room thermostat switches to comfort mode. If a night telegram is received, the ambient temperature controller switches to night mode. This object is controlled, for example, by time switches.

The second object can "overwrite" the first object temporarily. This means, for example, if a Freezing/Heat Protection telegram is received, the ambient temperature controller switches to Freezing or Heat Protection mode.

If freezing or heat protection is reset by another message, the ambient temperature controller activates the operating mode pending at the "normal" object. As a result, it is capable of noting operating modes.

The following applies to the 1-byte communication object:

0 = Auto

1 = Comfort

2 = Standby

3 = Night

4 = Freezing/Heat Protection

5 – 255 = not allowed

Enable switchover of comfort/standby via button On/Off

Options: Yes
 No

Use this parameter to enable switching between operating modes with the ON/OFF switch. If "No", ... is set here, the push-switch is used for switching the device on and off by pushing and holding (500 ms), if "Yes" is set, the operating mode can be switched from Comfort to Standby and vice versa by pushing and releasing the push-switch and the device is switched off by pushing and holding it (> 500ms). If the device is switched off and switched on with the ON/OFF push-switch, Comfort mode is set.

Operation mode after reset

- Options:
- **Comfort operation**
 - Standby
 - Night mode
 - Frost/heat protection

This parameter specifies the mode activated after resetting the temperature sensor or after commissioning. Comfort mode is default, however Standby, Night mode or Frost/heat Protection can also be selected.

3.2.2 "Temperature Measurement" parameter window

General	Offset for room temp. meas. (measured value change by (-128..127)x0.1 K)	0
Temperature measurement	Send actual value if change is larger than	Inactive
Controller general	Send actual value cyclically (0 - inactive, min)	0
Heating control	Measurement of room temperature	Interior
Cooling control	Monitoring temperature measurement	☐ Yes ☒ No
Setpoint general	Offset for ext. temp. meas. (measured value change by (-128..127)x0.1 K)	0
Manual setpoint		
Setpoints heat/cool		
FanCoil general		
FanCoil heating		
FanCoil cooling		

Offset for room temp. meas. (measured value changed by (-128..127)x0.1 K)

Options:

- -128
- ...
- **0**
- ...
- 127

Value range -128..127 corresponds to -12.8K..12.7K

If the actual temperature is recorded internally, it may be falsified by an additional internal heat source, e.g. bus or network coupler. The falsified value can be adjusted with the setting "calibration value for ambient temperature measurement".

Send actual value if change is larger than

Options:

- **Inactive**
- 0.1 K
- 0.2 K
- 0.3 K
- 0.4 K
- 0.5 K
- 0.6 K
- 0.7 K
- 0.8 K
- 0.9 K
- 1.0 K

If this parameter is set to a difference, the associated 2-byte communication object "Current temperature" sends its current temperature whenever this parameter changes.

Send actual value cyclically (0 – inactive, min)

Options: - 0 .. 60

If the current value is to be sent cyclically independent of a change, the parameter "Send actual value cyclically" must be set to a time. This may be necessary, for instance, with a higher-level boiler that expects to receive setpoints and current values within a certain time period. If values are not received, a predefined supply line temperature is set that is no longer oriented on actual demand.

Measurement of room temperature

Options: - Interior
- Exterior
- Interior and exterior

This parameter is used to set the measurement of the current temperature. It can be measured "Interior," "Exterior" or "Interior and Exterior". Internal measurement means that the temperature is taken directly from the room thermostat. For external measurements, an additional temperature sensor is used and is sent to the room thermostat via 2-byte communication object. If you are measuring current temperature internally and externally, the room thermostat determines the current temperature from the combination of temperature values defined in the "Emphasis internal/external" parameter. An additional sensor may need to be added for larger spaces.

Weighting interior / exterior

Options: - 10% / 90%
- 20 % / 80 %
- 30 % / 70 %
- 40 % / 60 %
- 50 % / 50 %
- 60 % / 40 %
- 70 % / 30 %
- 80 % / 20 %
- 90 % / 10 %

The "Weighting interior / exterior" specifies whether the internal temperature sensor for the ambient temperature controller is included in the control. If, for instance, the parameter is set to 60%, the current temperature is 60% of the temperature measured internally and 40% of the value obtained externally.

Monitoring temperature measurement

Options: - Yes
- No

The "Monitoring temperature measurement" parameter defines whether the internal and, if connected, external temperature sensors are to be monitored.

Control value at temp. measuring error

- Options:
- Final value
 - 0 %
 - 10 %
 - 20 %
 - 30 %
 - 40 %
 - 50 %
 - 60 %
 - 70 %
 - 80 %
 - 90 %
 - 100 %

In case of error the device output uses the specified value to run an emergency function.

Monitoring time exterior temperature (0 – inactive, min)

- Options: - 0 / 1 / ... / 10 / ... / 60

If the "Monitoring temperature measurement" parameter is set to "yes", the time within which the external temperature sensor must send a message to the bus is set here.

Monitoring time exterior temperature (0 – inactive, min)

- Options: - 0 / 1 / ... / 10 / ... / 60

If the "Monitoring temperature measurement" parameter is set to "yes", the time within which the outside temperature sensor must send a message to the bus is set here.

**Offset for ext. temp. meas.
(measured value changes by (-128..127)x0,1 K)**

- Options:
- -128
 - ...
 - **0**
 - ...
 - 127

Value range -128..127 corresponds to -12.8K..12.7K

The measured outside temperature can be adjusted with this parameter. This means that if the outside temperature is falsified by heat or cooling effects at the temperature sensor, the measured value can be adjusted up or down.

3.2.3 Parameter window "Controller general"

General	Operating mode of unit	☒ Normal operation with control function ☐ Ext. input, only operating and display fun...
Temperature measurement		
Controller general	Used control functions	Heat and cool
Heating control	Switchover between heating and cooling	Automatic
Cooling control	Additional heating stage active	☐ Yes ☒ No
Setpoint general	Additional cooling stage active	☐ Yes ☒ No
Manual setpoint	Condensate alarm active	☐ Yes ☒ No
Setpoints heat/cool	Dew-point alarm active	☐ Yes ☒ No
FanCoil general	Operation mode after reset	Heating
FanCoil heating	Number of output channels	☐ 1 channel (dual pipe system) for heat / cool ☒ 2 channels (four-pipe system) for heat / c...
FanCoil cooling		

Operating mode of unit

- Options:
- **Normal operation with control function**
 - Ext. input, only operating and display function

The control function of the device is deactivated in the "Ext. input, only operating and display function" setting. The device is used to

1. control another unit, such as switching on and off, setpoint input, fan stage, °C/°F switching
2. display, such as current temperature
3. recording current temperature

All unwanted communication objects and parameters are not shown.

The user cannot see whether it is normal mode or branch.

Used control functions

- Options:
- Heating
 - Cooling
 - **Heat and cool**

The parameter "Used control functions" allows you to define the functionality of the room thermostat. You can choose between "Heating" or "Cooling" functions, or use it for both "Heat and cool". Once you have selected a function, only the parameters and communication objects required for that function are shown. This setting is only shown if the operating mode of the device is set to normal mode with control function.

Switchover between heating and cooling

- Options:
- **Automatic**
 - Automatic and send
 - Exterior

You can switch between heating and cooling automatically in the room thermostat. To do so, select the "Automatic" option. This ensures that the room thermostat checks the configured setpoints for heating and cooling. The option "Automatic and send" also allows you to switch automatically. In addition, a toggle telegram is sent and can be analysed by other room thermostats. The "Exterior" option allows you to switch via an associated 1-bit communication object.

Additional heating stage active

- Options:
- Yes
 - **No**

In specific instances such as when using underfloor heating, it may be necessary to install a quick additional stage for the heat control in order to warm up the room rapidly. When the ambient temperature controller is set to "Yes", it has a second heating system with switching control (1-bit) or continuous control (1-byte).

This parameter is only available if the "Heating" or "Heat and cool" control functions are used.

Additional cooling stage active

- Options:
- Yes
 - **No**

In specific instances, it may be necessary to install a quick additional stage in the cooling control in order to cool off the room rapidly. When the ambient temperature controller is set to "Yes", it has a second cooling system with switching control (1-bit) or continuous control (1-byte) 100%.

This parameter is only available if the "Cooling" or "Heat and cool" control functions are used.

Condensate alarm active

Options: - Yes
 - No

If the parameter "Condensate alarm active" is activated, the room thermostat has a 1-bit communication object that can be used to send telegrams from a container for condensate water. When an ON telegram arrives, the room thermostat changes to the heat protection mode. Heat protection is deactivated when an OFF telegram is received. This prevents condensate, which can collect during cooling, from overflowing the condensate container.

This parameter is only available if the "Cooling" or "Heat and cool" control functions are used.

If a condensate collector alarm is detected, it is shown in the display (fault symbol plus abbreviation).

The frost protection object is sent in the event of a condensate alarm if the flag is set to send. If the condensate alarm is corrected and there is no dewpoint alarm, the device switches from heat protection back to the operating mode from the "operating mode after reset and Off" parameter.

Dew-point alarm active

Options: - Yes
 - No

If the parameter "Dew-point alarm active" is activated, the room thermostat has a 1-bit communication object that can be used to send telegrams from a dew point sensor. When an ON telegram arrives, the room thermostat changes to the heat protection mode. Heat protection is deactivated when an OFF telegram is received. This prevents the condensate that forms during incipient condensation when cooling is switched on from causing damage.

This parameter is only available if the "Cooling" or "Heat and cool" control functions are used.

If a dewpoint alarm is detected, it is shown in the display (fault symbol plus abbreviation).

The frost protection object is sent in the event of a dewpoint alarm if the flag is set to send. If the dewpoint alarm is corrected and there is no condensate collector alarm, the device switches from heat protection back to the operating mode from the "operating mode after reset and Off" parameter.

Operation mode after reset

- Options:
- **Heating**
 - Cooling
 - Dependent on object "switchover heat / cool"

This parameter specifies the mode activated after resetting the temperature sensor or after commissioning, if heating/cooling switching is set to external.

Heating is preset, otherwise the operating mode can depend on the value of the heating/cooling object. The device queries the value of the object over the bus during initialisation.

Note:

The selection option "Dependent on object switchover heat / cool" is only shown if the "switching between heating and cooling" is set to "Exterior".

Number of output channels

- Options:
- 1 channel (dual pipe system) for heat / cool
 - **2 channels (four-pipe system) for heat / cool**

If the "used control functions" parameter has been selected, it can be used to specify whether a separate communication object or a common communication object for heating or cooling is provided for the control value. The setting "1 channel (dual pipe system) for heat / cool" is required for dual pipe systems and the setting "2 channels (four-pipe system) for heat / cool" is required for four-pipe systems.

3.2.4 Parameter window "Heating control"

General	Status send heat requirement	☐ Yes ☒ No
Temperature measurement	Cycle time heating control value sending (0 - inactive, min)	0
Controller general		
Heating control	Control mode	FanCoil
Cooling control	Control value larger when sending change	0%
Setpoint general	Control parameter	☒ Acc. to installation type ☐ Free parameterization
Manual setpoint	Type of heating system	Split unit (4 K / 90 min)
Setpoints heat/cool	Minimum control value	0%
FanCoil general	Maximum control value	100%
FanCoil heating		
FanCoil cooling		

Status send heat requirement

Options: - Yes
 - **No**

If you set the "Status send heat requirement" to "yes", the ambient temperature controller will send an ON telegram via the relevant 1-bit communication object once it is in heating mode. If the room thermostat is in the "insensitive range" between heating and cooling or in cooling mode, the thermostat sends an OFF telegram via the status heating object. This parameter is only available if the "Heating" or "Heat and cool" control functions are set.

Cycle time heating control value sending (0 - inactive, min)

Options: - **0** / 1 / ... / 60

The room thermostat can send the control value, even if the value remains unchanged. This is often required since the connected actuator otherwise assumes that the room thermostat is no longer available. This enables the actuator to activate its force-position control, which is only deactivated when a new control value is received.

The cycle time for automatic sending of the control value is adjustable from 1 to 60 min. Cyclic sending can also be disabled (setting 0). This parameter is only available if the "Heating" or "Heat and cool" control functions are set.

Control mode

- Options:
- 2-step
 - PWM
 - Continuous
 - **FanCoil**

This function allows you to specify the mode of control. You can select "2-step control", "PWM control", "Continuous control" or "FanCoil actuation" (see also page 95 and following).

This parameter is only available if the "Heating" or "Heat and cool" control functions are set.

Note: the fan can be set with a push-switch in Fan Coil only. The push-switch has no function with other control types and fan stage display is hidden.

Hysteresis

- Options:
- 0.0 K
 - 0.1 K
 - 0.2 K
 - 0.3 K
 - 0.4 K
 - ...
 - **1.0 K**
 - ...
 - 2.0 K

Set a hysteresis value to ensure that the valve does not constantly switch with each minor under and overshoot when using 2-step control of the actuator. The hysteresis value lies around the setpoint. For example, if the setpoint is 21 °C and the hysteresis is 1 K, the room thermostat only sends an "on" signal at 21.5 °C and an "off" signal at 20.5 °C.

This parameter is only available if "2-step control" is set as the control type.

Invert heating

- Options:
- Yes
 - **No**

"Invert heating" is used to adjust the direction of control action of the control value to "de-energised open" or "de-energised closed" valves.

This parameter is only available if "2-step control" is set as the control type.

Control value larger when sending change

- Options:
- **0%**
 - 1 %
 - ...
 - 5 %
 - ...
 - 15 %

The parameter "Control value larger when sending change" can be used to influence the bus load. This setting is configured in percentages. The higher the selected value, the fewer the control value telegrams sent by the room thermostat. However, the value should not be set too high to ensure the control works properly. A value of 5% will generally provide good control results.

This parameter is only available if the "Heating" or "Heat and cool" control functions are set and the "Heating" control type is set to "Continuous" or "FanCoil".

Control parameter

- Options:
- **Acc. to installation type**
 - free parameterization

This parameter allows you to configure the control based on the type of system in use. The "Acc. to installation type" setting displays predefined values for the different system types that most frequently provide good control results. The setting "free parameterization" can be used to individually update the proportional range and readjust time. Proper knowledge in the field of control technology is required to use "free parameterization".

This parameter is only available if the "Heating" or "Heat and cool" control functions are set and the heating control type is set to "PWM", "Continuous" or "FanCoil".

Type of heating system

- Options:
- Warm water heating (1.5 K / 100 min)
 - Electric heating (1.5 K/50 min)
 - Floor heating (4 K/200 min)
 - **Split unit (4 K / 90 min)**

The "Type of heating system" parameter enables you to select the heating system in use with predefined control parameters.

This parameter is only available if the "Heating" or "Heat and cool" control functions are set, the heating control type is set to "PWM", "Continuous" or "FanCoil" and the control parameter is set to "via system type".

Proportional range (Xp)

- Options:
- 0.5 K
 - 1.0 K
 - 1.5 K
 - 2.0 K
 - 2.5 K
 - 3.0 K
 - 3.5 K
 - **4.0 K**
 - 4.5 K
 - 5.0 K
 - 5.5 K
 - ...
 - 10.0 K

The proportional range stands for the P amount of controller. It varies around the setpoint and can be used to influence control speed with a PI controller. The smaller the configured value, the faster it reacts to the control. This value should not be configured too low, in order to avoid risk of overshoot.

This parameter is only available if "free parameterization" is set as the control parameter.

Readjust time

- Options:
- 0 min
 - 10 min.
 - 20 min.
 - ...
 - **90 min**
 - ...
 - 240 min

The readjust time stands for the I amount of a controller. The integral amount has the effect of moving the room temperature slowly toward and finally to the setpoint. Depending on the system type used, the readjust time has to have different values. In general, the more inactive the overall system, the larger the readjust time.

This parameter is only available if "free parameterization" is set as the control parameter.

Minimum control value

- Options:
- **0 %**
 - 5%
 - 10 %
 - 15 %
 - 20 %
 - 25 %
 - 30 %

This parameter is required if the ambient temperature controller with constant control regulates a continuous actuator or a fan coil.

To prevent switching with control variables that are too small, the parameter "minimum control value" can be set to a value so that the actuator only switches on at larger control values.

This parameter is only available if the "Heating" or "Heat and cool" control functions are set and the "Heating" control type is set to "Continuous" or "FanCoil".

Maximum control value

- Options:
- 70%
 - 75%
 - 80 %
 - 85 %
 - 90 %
 - 95 %
 - **100 %**

This parameter is required if the ambient temperature controller with constant control regulates a continuous actuator or a fan coil. To prevent switching with control values that are too high, the parameter "maximum control value" can be set to a value so that the actuator switches off at lower control values.

This parameter is only available if the "Heating" or "Heat and cool" control functions are set and the "Heating" control type is set to "Continuous" or "FanCoil".

3.2.5 Parameter window "Controller PWM heating"

General	Invert heating	☐ Yes ☒ No
Temperature measurement	Cycle time PWM control value (min)	15
Controller general	PWM cycle is 0% up to control value	10%
Heating control	PWM cycle is 100 % up to control value	90%
Control PWM heating		
Cooling control		
Setpoint general		
Manual setpoint		
Setpoints heat/cool		
FanCoil general		
FanCoil cooling		

Invert heating

Options: - Yes
 - **No**

"Invert heating" is used to adjust the direction of control action of the control value to "de-energised open" or "de-energised closed" valves.

Cycle time PWM control value (min)

Options: - 1 / 2 / ... / **10** / ... /60

With PWM control, the actuator switches the valve drive depending on the control value. The control thereby checks the "Cyclic time of the PWM control value".

Example: for a cyclic time of 10 min. and a control value of 60%, the valve gear is switched on for 6 min. and off for 4 min.

Basically, the following applies for cyclic time: the more inactive the entire system, the higher the cyclic time you can set.

This parameter is only available if the "Heating" or "Heat and cool" control functions are used and the heating control type is set to "PWM".

PWM cycle is 0% up to control value

- Options:
- 0%
 - 5 %
 - ...
 - **10 %**
 - ...
 - 30 %

If the control value is very small for PWM control, the switch-on period for the actuator might not be sufficient to put in motion the connected thermoelectric valve gear. A valve drive opens or closes by warming or cooling an expansion element. However, it always takes time for the element to heat up or cool off sufficiently to allow the valve to be opened or closed. As a result, the valve might not even open with very small control values.

The parameter "PWM cycle is 0% up to control value" can be used to prevent switching with control values that are too small. This parameter allows you to configure the control value at which the actuator switches on. This parameter is only available if the "Heating" or "Heat and cool" control functions are used and the heating control type is set to "PWM".

PWM cycle is 100% up to control value

- Options:
- 70%
 - 75 %
 - ...
 - **90 %**
 - ...
 - 100 %

If the control value is very large for PWM control, the switch-off period for the actuator might not be sufficient to put in motion the connected thermoelectric valve gear. A valve drive opens or closes by warming or cooling an expansion element. However, it always takes time for the element to heat up or cool off sufficiently. As a result, the valve might not even close with very large control values.

The parameter "PWM cycle is 100% down to an output value" can be used to prevent switching with control values that are too large. It also sets the control value from which the actuator switches off.

This parameter is only available if the "Heating" or "Heat and cool" control functions are used and the heating control type is set to "PWM".

3.2.6 Parameter window "Cooling control"

General	Status send cooling requirement	☐ Yes ☒ No
Temperature measurement	Cycle time cooling control value sending (0 - inactive, min)	0
Controller general	Control mode	FanCoil
Heating control	Control value larger when sending change	0%
Control PWM heating		
Cooling control	Control parameter	☒ Acc. to installation type ☐ Free parameterization
Setpoint general	Type of cooling system	☐ Cool ceiling (5 K / 240 min) ☒ Split unit (blower convector 4 K / 90 min)
Manual setpoint	Minimum control value	0%
Setpoints heat/cool	Maximum control value	100%
FanCoil general		
FanCoil cooling		

Status send cooling requirement

Options: - Yes
 - **No**

If you set the "Status send cooling requirement" to "Yes", the room thermostat will send an ON telegram via the relevant 1-bit communication object once it is in cooling mode. If the ambient temperature controller is in the "insensitive range" between heating and cooling or in cooling mode, the thermostat sends an OFF telegram via the status heating object. This parameter is only available if the "Cooling" or "Heat and cool" control functions are used.

Cycle time cooling control value sending (0 - inactive, min)

Options: - **0** / 1 / 2 / ... / 60

The room thermostat can send the control value, even if the value remains unchanged. This is often required since the connected actuator otherwise assumes that the room thermostat is no longer available. This enables the actuator to activate its force-position control, which is only deactivated when a new control value is received.

The cycle time for automatic sending is adjustable. Cyclic sending can also be disabled.

This parameter is only available if the "Cooling" or "Heat and cool" control functions are used and the control type is set to "2-step control", "Continuous" or "FanCoil".

Control mode

- Options:
- 2-step
 - PWM
 - Continuous
 - **FanCoil**

This function allows you to specify the type of control. You can choose from 2-step control, PWM control, Continuous control or FanCoil control. This parameter is only available if the "Cooling" or "Heat and cool" control functions are used.

Hysteresis

- Options:
- 0.0 K
 - 0.1 K
 - 0.2 K
 - 0.3 K
 - ...
 - **1.0 K**
 - ...
 - 2.0 K

Set a hysteresis value to ensure that the valve does not constantly switch with each minor under and overshoot when using 2-point control of the actuator. The hysteresis value lies around the setpoint. For example, if the setpoint is 26 °C and the hysteresis is 1 K, the room thermostat when cooling sends only an "on" signal at 25.5 °C and an "off" signal at 26.5 °C. This parameter is only available if "2-step control" is set as the control type.

Invert cooling

- Options:
- Yes
 - **No**

"Invert cooling" is used to adjust the direction of control action of the control value to "de-energised open" or "de-energised closed" valves. This parameter is only available if "2-step control" is set as the control type.

Control value larger when sending change

- Options:
- **0%**
 - 1 %
 - ...
 - 5%
 - ...
 - 15 %

The parameter "Control value larger when sending change" can be used to influence the bus load. This setting is configured in percentages. The higher the selected value, the fewer the control value telegrams sent by the room thermostat. However, the value should not be set too high to ensure the control works properly. A value of 5% will generally provide good control results.

This parameter is only available if the "Cooling" or "Heat and cool" control functions are used and the cooling control type is set to "Continuous" or "FanCoil".

Control parameter

- Options:
- **Acc. to installation type**
 - free parameterization

This parameter allows you to configure the control based on the type of system in use. The "Acc. to installation type" setting displays predefined values for the different system types that most frequently provide good control results. The setting "free parameterization" can be used to individually update the proportional range and readjust time. Proper knowledge in the field of control technology is required to use "free parameterization".

This parameter is only available if the "Cooling" or "Heat and cool" control functions are used and the cooling control type is set to "PWM", "Continuous" or "FanCoil".

Type of cooling system

- Options:
- Cool ceiling (5 K / 240 min)
 - **Split unit (blower convector 4 K / 90 min)**

The "Type of cooling" parameter enables you to select the cooling system in use with predefined control parameters.

This parameter is only available if the "Cooling" or "Heat and cool" control functions are used and the cooling control type is set to "PWM", "Continuous" or "FanCoil".

Proportional range (Xp)

Options:

- 0.5 K
- 1.0 K
- 1.5 K
- 2.0 K
- 2.5 K
- 3.0 K
- 3.5 K
- **4.0 K**
- 4.5 K
- 5.0 K
- 5.5 K
- 6.0 K
- 6.5 K
- 7.0 K
- 8.0 K
- 9.0 K
- 10.0 K

The proportional range stands for the P amount of controller. It varies around the setpoint and can be used to influence control speed with a PI controller. The smaller the configured value, the faster it reacts to the control. This value should not be configured too low, in order to avoid risk of overshoot.

This parameter is only available if "free parameterization" is set as the control parameter.

Readjust time (Tn)

Options:

- 0 min
- 10 min.
- 20 min.
- ...
- **90 min**
- ...
- 240 min

The readjust time stands for the I amount of a controller. The integral amount has the effect of moving the room temperature slowly toward and finally to the setpoint. Depending on the system type used, the readjust time has to have different values. In general, the more inactive the overall system, the larger the readjust time.

This parameter is only available if "free parameterization" is set as the control parameter.

Minimum control value

- Options:
- **0%**
 - 5%
 - 10 %
 - 15 %
 - 20 %
 - 25 %
 - 30 %

This parameter is required if the ambient temperature controller with constant control regulates a continuous actuator or a fan coil. To prevent switching with control variables that are too small, the parameter "minimum control value" can be set to a value so that the actuator only switches on at larger control values. This parameter is only available if the "Cooling" or "Heat and cool" control functions are used and the cooling control type is set to "Continuous" or "FanCoil".

Maximum control value

- Options:
- 70%
 - 75%
 - 80 %
 - 85 %
 - 90 %
 - 95 %
 - **100 %**

This parameter is required if the ambient temperature controller with constant control regulates a continuous actuator or a fan coil. To prevent switching with control values that are too high, the parameter "maximum control value" can be set to a value so that the actuator switches off at lower control values. This parameter is only available if the "Cooling" or "Heat and cool" control functions are used and the cooling control type is set to "Continuous" or "FanCoil".

3.2.7 Parameter window
"Control PWM cooling"

General	Invert cooling	☐ Yes ☒ No
Temperature measurement	Cycle time PWM control value (min)	15
Controller general	PWM cycle is 0% up to control value	10%
Heating control	PWM cycle is 100 % up to control value	90%
Control PWM heating		
Cooling control		
Control PWM cooling		
Setpoint general		
Manual setpoint		
Setpoints heat/cool		
FanCoil general		

Invert cooling

Options: - Yes
 - **No**

"Invert cooling" is used to adjust the direction of control action of the control value to "de-energised open" or "de-energised closed" valves.

Cycle time PWM control value (min)

Options: - 0 / 1 / 2 / ... / **10** / ... / 60

With PWM control, the actuator switches the valve drive depending on the control value. The control thereby checks the "Cyclic time of the switching control value".
Example: for a cyclic time of 10 min. and a control value of 60%, the valve gear is switched on for 6 min. and off for 4 min.
Basically, the following applies for cyclic time: the more inactive the entire system, the higher the cyclic time you can set.
This parameter is only available if the "Cooling" or "Heat and cool" control functions are used and the cooling control type is set to "PWM".

PWM cycle is 0% up to control value

- Options:
- 0%
 - 5 %
 - ...
 - **10 %**
 - ...
 - 30 %

If the control value is very small for PWM control, the switch-on period for the actuator might not be sufficient to put in motion the connected thermoelectric valve gear. A valve drive opens or closes by warming or cooling an expansion element. However, it always takes time for the element to heat up or cool off sufficiently to allow the valve to be opened or closed. As a result, the valve might not even open with very small control values.

The parameter "PWM cycle is 0% up to control value" can be used to prevent switching with control values that are too small. This parameter allows you to configure the control value at which the actuator switches on. This parameter is only available if the "Cooling" or "Heat and cool" control functions are used and the cooling control type is set to "PWM".

PWM cycle is 100% up to control value

- Options:
- 70%
 - 75 %
 - ...
 - **90 %**
 - ...
 - 100 %

If the control value is very large for PWM control, the switch-off period for the actuator might not be sufficient to put in motion the connected thermoelectric valve gear. A valve drive opens or closes by warming or cooling an expansion element. However, it always takes time for the element to heat up or cool off sufficiently. As a result, the valve might not even open with very large control values.

The parameter "PWM cycle is 100% up to an output value" can be used to prevent switching with control values that are too large. This parameter allows you to configure the control value at which the actuator switches on. This parameter is only available if the "Cooling" or "Heat and cool" control functions are used and the cooling control type is set to "PWM".

3.2.8 Parameter window "Additional heating"

General	Type of control value	☐ Continuous (1 Byte) ☒ Switching (1 Bit)
Temperature measurement	Invert control value	☐ Yes ☒ No
Controller general	Hysteresis (one-sided)	1,0 K
Heating control	Cycle time for sending of control value (0 - inactive, min)	0
Cooling control	Interval of additional level (value change by (0..127)x0.1 K)	30
Additional heating		
Additional cooling stage		
Setpoint general		
Manual setpoint		
Setpoints heat/cool		
FanCoil general		
FanCoil heating		
FanCoil cooling		

Type of control value

Options:

- Continuous (1 Byte)
- **Switching (1 Bit)**

The additional stage for heating can transmit a 1-bit or 1-byte sized control value. If "switching 1-Bit" is selected, the additional stage controls a switching control (1-bit) via a 1-bit communication object, e.g., a thermoelectric actuator that controls a switch actuator. If "Continuous 1-Bit" is selected, the additional stage provides continuous control (1-bit) via a 1-bit communication object, e.g., an electrical drive or an actuator with integrated pulse width modulation.

This parameter is only available if the "Heating" or "Heat and cool" control functions are used.

Invert control value

Options:

- Yes
- **No**

"Invert cooling" is used to adjust the direction of control action of the control value to "de-energised open" or "de-energised closed" valves. This parameter is only available if the "Heating" or "Heat and cool" control functions are used.

Hysteresis (one-sided)

Options: - 0.0 K
 - 0.1 K
 - 0.2 K
 - 0.3 K
 ...
 - **1.00 K**
 ...
 - 2.00 K

The parameters "Interval of additional level" and "Hysteresis (one-sided)" enable you to specify when the additional stage switches on and off. For example, if the setpoint for the additional stage is 18 °C and the hysteresis is 0.5 K (one-sided), the additional stage will switch on at 18 °C and off at 18.5 °C.

This parameter is only available if the "Heating" or "Heat and cool" control functions are used.

Cycle time for sending of control value (0 - inactive, min)

Options: - **0** / 1 / 2 / ... / 60

The room thermostat can send the control value, even if the value remains unchanged. This is often required since the connected actuator otherwise assumes that the room thermostat is no longer available. This enables the actuator to activate its force-position control, which is only deactivated when a new control value is received.

The cycle time for automatic sending is adjustable. Cyclic sending can also be disabled.

This parameter is only available if the "Heating" or "Heat and cool" control functions are used.

Interval of additional level (values changed by (0..127)x0.1 K)

Options: - 0
 - ...
 - **30**
 ...
 - 127

Value range 0..127 corresponds to 0K..12.7K

This parameter allows you to specify the setpoint of the additional stage for heating. The setpoint refers to the base setpoint for heating (comfort temperature for heating) for the basic stage.

Example: the basic setpoint for heating is set to 21 °C. When the temperature falls below 18 °C, additional heating should be switched on so that the room heats up again rapidly. In this event, set the parameter "Stage gap for the basic stage to additional stage" to 3 K. This may be necessary after automatic night setback, if the user wishes to use the room immediately (e.g., the bathroom early in the morning).

This parameter is only available if the "Heating" or "Heat and cool" control functions are used.

3.2.9 Parameter window "Additional cooling stage"

General	Type of control value	☐ Continuous (1 Byte) ☒ Switching (1 Bit)
Temperature measurement	Invert control value	☐ Yes ☒ No
Controller general	Hysteresis (one-sided)	1,0 K
Heating control	Cycle time for sending of control value (0 - inactive, min)	0
Cooling control	Interval of additional level (value change by (0..127)x0.1 K)	30
Additional heating		
Additional cooling stage		
Setpoint general		
Manual setpoint		
Setpoints heat/cool		
FanCoil general		
FanCoil heating		
FanCoil cooling		

Type of control value

- Options:
- Continuous (1 Byte)
 - **Switching (1 Bit)**

The additional stage for cooling can transmit a 1-bit or 1-byte sized control value. If "Switching 1-Bit" is selected, the additional stage controls a switching control (1-bit) via a 1-bit communication object, e.g., a thermoelectric actuator that controls a switch actuator. If "Continuous 1-Bit" is selected, the additional stage provides continuous control (1-byte) via a 1-byte communication object, e.g., an actuator with integrated pulse width modulation.

This parameter is only available if the "Cooling" or "Heat and cool" control functions are used.

Invert control value

- Options:
- Yes
 - **No**

The control value is adjusted to "de-energised open" or "de-energised closed" valves via the direction of control action of the controller. This parameter is only available if the "Cooling" or "Heat and cool" control functions are used.

Hysteresis (one-sided)

Options: - 0.0 K
 - 0.1 K
 - 0.2 K
 - 0.3 K
 ...
 - **1.0 K**
 ...
 - 2.00 K

The parameters "Interval of additional level" and "Hysteresis (one-sided)" enable you to specify when the additional stage switches on and off. For example, if the setpoint for the additional stage is 29 °C and the hysteresis is 0.5 K (one-sided), the additional stage switches on at 29 °C and off at 28.5 °C.

This parameter is only available if the "Cooling" or "Heat and cool" control functions are used.

Cycle time for sending of control value (0 - inactive, min)

Options: - **0** / 1 / 2 / ... / 60

The room thermostat can send the control value, even if the value remains unchanged. This is often required since the connected actuator otherwise assumes that the room thermostat is no longer available. This enables the actuator to activate its force-position control, which is only deactivated when a new control value is received.

The cycle time for automatic sending is adjustable. Cyclic sending can also be disabled.

This parameter is only available if the "Cooling" or "Heat and cool" control functions are used.

Interval of additional level (values changed by (0..127)x0.1 K)

Options: - 0
 - ...
 - **30**
 - 127

Value range 0..127 corresponds to 0K..12.7K

This parameter allows you to specify the setpoint of the additional stage for cooling. The setpoint refers to the base setpoint for cooling (comfort temperature for cooling) for the basic stage.

Example: the basic setpoint for cooling is set to 26 °C. When the temperature rises above 29 °C, additional cooling should be switched on so that the room cools off again rapidly. In this event, set the parameter "Stage gap for the basic stage to additional stage" to 3 K.

This parameter is only available if the "Cooling" or "Heat and cool" control functions are used.

3.2.10 Parameter window "Setpoint general"

General	Setpoint larger when sending change	Inactive
Temperature measurement	Cyclic sending of setpoint (0 - inactive, min)	0
Controller general	Select base setpoint	☒ Dependent setpoints ☐ Single setpoints
Heating control	Reference base setpoint	Setpoint heating
Cooling control	Manual setpoint adjustment at reset of change from night / to night	☒ Yes ☐ No
Setpoint general		
Manual setpoint		
Setpoints heat/cool		
FanCoil general		
FanCoil heating		
FanCoil cooling		

Setpoint larger when sending change

Options: - Inactive
 - 0.1 K
 - 0.2 K
 - 0.3 K
 - 0.4 K
 - 0.5 K
 - 0.6 K
 - 0.7 K
 - 0.8 K
 - 0.9 K
 - 1.0 K

If this parameter is set to a difference, the associated 2-byte communication object "Setpoint temperature" sends its current temperature whenever this parameter changes more than the specified difference.

Cyclic sending of setpoint (0 – inactive, min)

Options: - 0 / 1 / 2 / ... / 60

If the setpoint is to be sent cyclically independent of a change, the parameter "Cyclic sending of setpoint" must be set to a time. This may be necessary, for instance, with a higher-level boiler that expects to receive setpoints and current values within a certain time period. If values are not received, a predefined supply line temperature is set that is no longer oriented on actual demand.

Select base setpoint

- Options:
- **Dependent setpoints**
 - Single setpoints

The "Select base setpoint" option defines whether the room thermostat refers to "Dependent setpoints" or to "Single setpoints".

Dependent setpoints mean that a comfort temperature (base setpoint) is defined and other setpoints such as temperature at standby or automatic night setback refer to this point.

The standby temperature 2 K is set lower than the comfort temperature (base setpoint). At a comfort temperature of 21 °C this means a standby temperature of 19 °C. If you raise the comfort temperature to 22 °C by manually moving the setpoint, the standby temperature is automatically changed to 20 °C.

The setting "Single setpoints" allows you to choose a separate temperature on the room thermostat for each setpoint; the room thermostat always refers to this setting in the respective operating mode.

Example: the standby temperature is set permanently at 19 °C. If you raise the comfort temperature from 21 °C to 22 °C by manually moving the setpoint, the standby temperature does not change.

Reference base setpoint

- Options:
- **Setpoint heating**
 - Setpoint cooling
 - Mid skip zone

If "Dependent setpoints" were selected with "Heat and cool" controller function and selection of base setpoint, this parameter can be used to define whether the base setpoint refers to comfort temperature for heating, cooling or the average temperature between "Heat and cool" (see also page 103, Section 4.4.3 Minimum distance).

"Setpoint heating" is the default setting. In regions where the cooling function is more important, it is recommended that you change this parameter to "Setpoint cooling". This makes it easier to set the room thermostat and raise the cooling setpoint (standby temperature cooling and automatic night setback).

This parameter is only available if the "Heat and cool" control functions are set.

Manual setpoint adjustment at reset of change from night / to night

Options: - Yes
 - No

If this parameter is set to "Yes", the setpoint offset is automatically reset when switching operating modes from night and to night.

If a setpoint is adjusted manually, the increase or reduction of the setpoint can be cancelled if the operating mode is changed, e.g. on receipt of a telegram from a timer. This means that if the parameter is set to "Yes", the manually adjusted setpoint will be rejected if the operating mode changes and it will be reset to the setpoint preset in the parameter.

3.2.11 Parameter window
"Manual setpoint"

General	Manual setpoint adjustment	☐ Disabled ☒ Active
Temperature measurement	Maximum manual setpoint increase	3
Controller general	Maximum manual setpoint reduction	3
Heating control	Object reset manual setpoint adjustment active	☐ Yes ☒ No
Cooling control	When receiving base setpoint	☒ Retain manual setpoint adjustment ☐ Reset manual setpoint adjustment
Setpoint general		
Manual setpoint		
Setpoints heat/cool	Range manual setpoint adjustment	0,5 K
FanCoil general	Long press of button to enable change of setpoint heating / cooling	☐ Yes ☒ No
FanCoil heating		
FanCoil cooling		

Manual setpoint adjustment

Options:

- Disabled
- **Active**

This parameter allows end users to adjust the configured setpoint during commissioning. The settings "... manual increase and reduction of the setpoint" is used to specify how high or low the setpoint can be moved. The value that is parameterised for manually configuring the setpoint is an amount that fluctuates around the setpoint.
Example: with a comfort temperature of 21 °C and a manual setpoint adjustment of +/- 3 K, users can select any temperature from 18 °C to 24 °C.

Maximum manual setpoint increase

- Options:
- 0 K
 - 1 K
 - 2 K
 - **3 K**
 - 4 K
 - 5 K
 - 6 K
 - 7 K
 - 8 K
 - 9 K
 - 10 K

If you wish to prevent an excessive temperature increase by the manual setpoint setting, the upper range of the manual setpoint preset can be limited with the parameter "Maximum manual setpoint increase".
Example: with a comfort heating temperature of 21 °C and a manual setpoint adjustment of +/- 3 K, users can select any temperature from 18 °C to 24 °C. If the comfort temperature can be increased to a maximum of 22 °C, enter "1 K" under the parameter "Max. increase of setpoint".

Maximum manual setpoint reduction

- Options:
- 0 K
 - 1 K
 - 2 K
 - **3 K**
 - 4 K
 - 5 K
 - 6 K
 - 7 K
 - 8 K
 - 9 K
 - 10 K

If you wish to prevent an excessive temperature reduction by the manual setpoint setting, the lower range of the manual setpoint preset can be limited with the parameter "Maximum manual setpoint reduction".
Example: with a comfort cooling temperature of 26 °C and a manual setpoint adjustment of +/- 3 K, users can select any temperature from 23 °C to 29 °C. If the comfort temperature can be reduced to a maximum of 25 °C, enter "1 K" under the parameter "Max. reduction of setpoint".

Object reset of manual setpoint adjustment active

- Options:
- Yes
 - **No**

This parameter releases a 1-bit communication object that upon receipt of an ON telegram can be used manually reset the setpoint adjustment. This is required, for instance, if a central function is triggered that is intended to reset all the room thermostats to their default settings. All manual setpoint adjustments are reset for both "dependent" setpoints and "individual" setpoints.

When receiving base setpoint

- Options:
- **Retain manual setpoint adjustment**
 - Reset manual setpoint adjustment

If a new base setpoint is received by the ambient temperature controller via KNX telegram after manually adjusting the setpoint, the ambient temperature controller can also reset the manually adjusted setpoint. The behaviour of the ambient temperature controller when receiving a base setpoint value can be configured via this parameter. The manually configured setpoint is either reset or remains unchanged. This refers to all setpoints for "dependent" setpoints and the base setpoint that was received for "individual" setpoints, e.g. "heating setpoint comfort mode".

Range manual setpoint adjustment

- Options:
- 0.1 K
 - 0.2 K
 - 0.3 K
 - 0.4 K
 - **0.5 K**
 - 0.6 K
 - 0.7 K
 - 0.8 K
 - 0.9 K
 - 1.0 K

The user can adjust the preset setpoint as required with the two push-switches, "increase" and "reduce". The parameter "Jump displacement manual setpoint adjustment" is used to define how many K the presetpoint is to be increased or reduced when a push-switch is pressed.

Long press of button to enable change of setpoint heating / cooling

- Options:
- Yes
 - **No**

If the parameter is set to "Yes", the user can press and hold the "Temperature up" push-switch (approx. 1 s) to switch to the heating setpoint and press and hold the "temperature down" push-switch to switch to the cooling setpoint.

3.2.12 Parameter window
"Setpoint heat/cool"

General	Heating setpoint comfort mode	21,0 °C
Temperature measurement	Heating setpoint reduction standby	2,0 K
Controller general	Heating setpoint reduction night operation	4,0 K
Heating control	Cooling setpoint comfort mode	23,0 °C
Cooling control	Cooling setpoint increase standby	2,0 K
Setpoint general	Cooling setpoint increase night mode	4,0 K
Manual setpoint	Setpoint frost protection	7 °C
Setpoints heat/cool	Setpoint heat protection	Cooling disabled
FanCoil general	Minimum distance between heating setpoint and cooling setpoint	2,0 K
FanCoil heating		
FanCoil cooling		

Heating setpoint comfort mode

- Options:
- 16.0 °C
 - 16.5 °C
 - ...
 - **21.0 °C**
 - ...
 - 31.0 °C

The "Heating setpoint comfort mode" specifies the individual comfort temperature for the heating mode. This parameter is only available if the "Heating" or "Heat and cool" control functions are used, in which the setpoints "Dependent setpoints" (tab "Setpoints general") have been selected and the reference of the base setpoint has been set to "Base setpoint heating".

Heating setpoint reduction standby

- Options:
- 0.5 K
 - 1.0 K
 - ...
 - **2 K**
 - ...
 - 8.0 K

The setting "Heating setpoint reduction standby" allows you to specify the number of degrees Kelvin that the comfort temperature is lowered during standby operation. This parameter is only available if the parameter "Selection of base setpoint" (tab "Setpoint general") is set to "Dependent setpoints".

Heating setpoint reduction night operation

Options:

- 0.5 K
- 1.0 K
- ...
- **4 K**
- ...
- 8.0 K

The setting "Heating setpoint reduction night operation" allows you to specify the number of degrees Kelvin that the comfort temperature is lowered during night mode.

This parameter is only available if the parameter "Selection of base setpoint" (tab "Setpoint general") is set to "dependent setpoints".

Heating setpoint standby mode

Options:

- 14.0 °C
- 14.5 °C
- ...
- **19.0 °C**
- ...
- 29.0 °C

"Heating setpoint for standby mode" specifies the individual standby temperature for heating mode. The temperature value specified does not depend on the specified "Heating setpoint comfort mode".

This parameter is only available if the parameter "Selection of base setpoint" (tab "Setpoint general") is set to "individual setpoints".

Heating setpoint night mode

Options:

- 10.0 °C
- 10.5 °C
- ...
- **15.0 °C**
- ...
- 25.0 °C

The "Heating setpoint night mode" specifies the individual temperature during the night for heating mode. The temperature value specified does not depend on the specified "Heating setpoint comfort mode".

This parameter is only available if the parameter "Selection of base setpoint" (tab "Setpoint general") is set to "Individual setpoints".

Cooling setpoint comfort mode

Options:

- 16.0 °C
- 16.5 °C
- ...
- **23.0 °C**
- ...
- 31.0 °C

The "Cooling setpoint comfort mode" specifies the individual comfort temperature for the cooling mode. This parameter is only available if the "Cooling" or "Heat and cool" control functions are used, in which the setpoints "dependent setpoints" (tab "Setpoints general") have been selected.

Cooling setpoint increase standby

Options:

- 0.5 K
- 1.0 K
- ...
- **2 K**
- ...
- 8.0 K

The setting "Cooling setpoint increase standby" allows you to specify the number of degrees Kelvin that the comfort temperature is increased during standby operation.

This parameter is only available if the parameter "Selection of base setpoint" (tab "Setpoint general") is set to "Dependent setpoints".

Cooling setpoint increase night mode

Options:

- 0.5 K
- 1.0 K
- ...
- **4 K**
- ...
- 8.0 K

"Cooling setpoint increase night mode" allows you to specify the number of degrees Kelvin that the comfort temperature is raised during night operation. This parameter is only available if the parameter "Selection of base setpoint" (tab "Setpoint general") is set to "Dependent setpoints".

Cooling setpoint standby mode

Options: - 21.0 °C
 - 21.5 °C
 - ...
 - **25.0 °C**
 - ...
 - 36.0 °C

"Cooling setpoint for standby mode" specifies the individual standby temperature for cooling mode. The temperature value specified does not depend on the specified "Cooling setpoint comfort mode". This parameter is only available if the parameter "Selection of base setpoint" (tab "Setpoint general") is set to "Individual setpoints".

Cooling setpoint night mode

Options: - 23.0 °C
 - 23.5 °C
 - ...
 - **27.0 °C**
 - ...
 - 38.0 °C

"Cooling setpoint night mode" specifies the individual temperature during the night for cooling mode. The temperature value specified does not depend on the specified "Cooling setpoint comfort mode". This parameter is only available if the parameter "Selection of base setpoint" (tab "Setpoint general") is set to "Individual setpoints".

Minimum distance between heating setpoint and cooling setpoint

Options: - 0.0 K
 - 0.5 K
 - ...
 - **2 K**
 - ...
 - 7.5 K

The comfort temperature for cooling can be adjusted with "Minimum distance between heating and cooling". The cooling setpoint increases for standby and night mode are based on this value. If, for instance, with a comfort temperature (base setpoint) of 21 °C you want to cool at 26 °C in comfort mode, you have to set a dead zone of 5 K (see also page 103 Section 4.4.3 Minimum distance). This parameter is only available if the parameter "Selection of base setpoint" (tab "Setpoint general") is set to "Dependent setpoints".

Setpoint frost protection

- Options:
- 0 °C
 - 1 °C
 - ...
 - **7 °C**
 - ...
 - 15 °C

The setpoint for frost protection is the temperature that may not be undershot during the frost protection mode. If the current temperature undershoots the configured value, the ambient temperature controller triggers a control value telegram that causes the relevant heating actuator to heat up the room to prevent damage to the heating system from frost-related cooling.

This parameter is only available if the "Heating" or "Heat and cool" control functions are used.

Setpoint heat protection

- Options:
- 30.0 °C
 - 30.5 °C
 - ...
 - ...
 - 44.0 °C
 - **Cooling disabled**

The setpoint for heat protection is the temperature that may not be overshoot during heat protection mode. If the current temperature overshoots the configured value, the ambient temperature controller triggers a control value telegram that causes the relevant cooling unit to cool the room to prevent damage from heat build-up.

This parameter is only available if the "Cooling" or "Heat and cool" control functions are used.

Note:

At the setpoint 99.9 °C is sent at "Cooling disabled".

3.2.13 Parameter window
"FanCoil general"

General	Number of fan levels	3 levels
Temperature measurement		
Controller general	Manual operation of fan stage is signaled to the actuator via	☒ Object "Automatic ON/OFF" ☐ Object "Manual ON/OFF"
Heating control	Object manual fan stage send hat has the following code	1-Byte object as counting value 0-3
Cooling control	Evaluate status byte fan stage	☐ Yes ☒ No
Setpoint general	Evaluate status byte operation	☐ Yes ☒ No
Manual setpoint		
Setpoints heat/cool	Stage of fan after reset	Automatic
FanCoil general		
FanCoil heating		
FanCoil cooling		

Number of fan levels

- Options:
- 1 level
 - 2 levels
 - **3 levels**

The parameter "Number of fan levels" allows you to specify the number of fan stages that should be controlled for a fan coil actuator. You can select from one, two or three stages. The ambient temperature controller always provides a 1-byte communication object (see object: "Send manual fan level" has the following coding) and also provides exactly as many 1-bit communication objects as the number of fan stages selected. Most importantly, the number selected must match the actual number of fan stages. An actuator is therefore actuated either by the 1-byte communication object or the 1-bit communication object.

Manual operation of the fan stage is signaled to the actuator via

- Options:
- Object "Automatic ON/OFF..."**
 - Object "Manual ON/OFF..."

This specifies which object sends the information to the actuator or whether the fan stage is being manually operated by the user. he only difference between the objects is the coding.

"Automatic ON/OFF" = 1, if manual operation is not enabled

"Manual ON/OFF" = 1, if manual operation is not enabled

Object manual fan stage send has the following code

- Options:
- 1-Byte object as constant value 0-100%
 - **1-Byte object as counting value 0-3**
 - 1-Bit Values

If the user has made a manual fan stage switch, it can be sent to the KNX. The parameter "Manual fan stage send has the following code" can be used to enable a 1-byte object or three 1-bit objects.

The selected fan stage can be sent via the 1-byte object as a counter value from 0 to 3 (0=no manual switch) or the continuous value from 0 to 100 %. The continuous values for output are specified by the settings in the threshold values for the specific stage.

When 1-bit values are selected, a 1-bit communication object is available for every fan stage. If the fan stage is manually switched, an OB telegram is sent via the corresponding object. An OFF telegram is sent if the manual switch is cancelled.

Evaluate status byte operation

- Options:
- Yes
 - **No**

If this parameter is set to "Yes", the ambient temperature controller can analyse a stage status message that is received by a fan-coil actuator. This releases a 1-byte communication object that is used to evaluate the stage at which the fan coil actuator is activated.

This parameter is only available if the "Heating" or "Heat and cool" control functions are used and the heating control type is set to "FanCoil".

Evaluate status byte operation

- Options:
- Yes
 - **No**

If this parameter is set to "Yes", the ambient temperature controller can analyse an operating status message that is received by a fan-coil actuator. 1-bit communication object is enabled which is used to evaluate whether the fan coil actuator is currently in operation. If a fault is detected, it is indicated by the fault symbol in the display.

This parameter is only available if the "Heating" or "Heat and cool" control functions are used and the heating control type is set to "FanCoil".

Send cycle time of actuator in s (1 ..65,535)Options: 1 / 2 / ... / **120** / ... / 65.535

If the "Status byte operation" object is enabled and connected to the corresponding communication object of the fan coil actuator, the ambient temperature controller expects a cyclic transmission of the operating status of the linked fan coil actuator. If a message from the actuator is not sent within the monitoring time "Send cycle time of actuator in s" at least once, the ambient temperature controller automatically shows the fault display. The cycle time of the actuator should therefore be set to ensure that a telegram is sent at least twice during "Send cycle time of actuator in s".

Stage of fan after reset

Options:

- Off
- Stage 1
- Stage 2
- Stage 3
- **Automatic**

The parameter "Stage of fan after reset and after off" is used to prevent undefined states after a reset or switching off the ambient temperature controller. It specifies whether the fan switches on the first, second or third stage, switches off or switches to automatic mode.

Note: automatic mode means that the fan coil actuator switches the fan stages based on the received 1-byte control value.

3.2.14 Parameter window "FanCoil heating"

General	Stage limit in night mode	No limit
Temperature measurement	Automatic return from manual adjustment (0 - inactive, min)	0
Controller general	Return inactive a fan stage off and automatic return not 0	☒ Yes ☐ No
Heating control	Threshold value stage 1	10
Cooling control	Threshold value stage 2	40
Setpoint general	Threshold value stage 3	70
Manual setpoint		
Setpoints heat/cool		
FanCoil general		
FanCoil heating		
FanCoil cooling		

Stage limit in night mode

Options: - **No limit**
 - Fan Off
 - Stage 1
 - Stage 2

If the device is used in an environment such as a hotel room, it may be desirable to limit the fan stages during the night to reduce the noise. The parameter "Stage limit in night mode" is used for this. If the parameter is set to stage 1, the fan will not use more than the first stage when night mode is enabled. This will apply even if the transmitted control value requests a higher fan stage.

Automatic return from manual adjustment (0 - inactive, min)

Options: - **0** / 1 / 2 / ... / 60

If "Manual stage switching" was performed by the user, this action can be reset via onsite operation of the ambient temperature controller. However, a time can also be input after which the ambient temperature cancels the "Manual stage switching" and switches back to automatic stage switching mode.

This parameter is only available if the "Heating" or "Heat and cool" control functions are used and the heating control type is set to "FanCoil".

Return inactive a fan stage of and automatic return not 0

Options: - **Yes**
 - No

If the user has manually changed the stage to "switch off", the ambient temperature controller can also be set so that it does not return to automatic switching at the end of the "manual switching period" but rather remains switched off.

This parameter is only available if the "Heating" or "Heat and cool" control functions are used and the heating control type is set to "FanCoil".

Threshold value stage 1

Options: - 0%
 - **10 %**
 - ...
 - 50 %
 - ...
 - 100 %

Threshold value stage 1 specifies the magnitude of the control value required to switch the ambient temperature controller to fan stage 1. The threshold can be defined in percentages. Make sure that the threshold for stage 1 is not set higher than the threshold for stage 2 (if available). This parameter is only available if the "Heating" or "Heat and cool" control functions are used, the heating control type is set to "FanCoil" and the number of fan stages is min. "1 stage"..

Threshold value stage 2

Options: - 0%
 - 10 %
 - ...
 - **40 %**
 - ...
 - 100 %

Threshold value stage 2 specifies the magnitude of the control value required to switch the ambient temperature controller from fan stage 1 to fan stage 2. The threshold can be defined in percentages. Make sure that the threshold for stage 1 is not set higher than the threshold for stage 2 (if available)

This parameter is only available if the "Heating" or "Heat and cool" control functions are used, the heating control type is set to "FanCoil" and the number of fan stages is min. "2 stage".

Threshold value stage 3

Options:

- 0%
- 10 %
- ...
- **70 %**
- ...
- 100 %

Threshold value stage 3 specifies the magnitude of the control value required to switch the ambient temperature controller from fan stage 2 to fan stage 3. The threshold can be defined in percentages. Make sure that the threshold for stage 3 is not set higher than the threshold for stage 3 (if available).

This parameter is only available if the "Heating" or "Heat and cool" control functions are used, the heating control type is set to "FanCoil" and the number of fan stages is min. "3 stage".

3.2.15 Parameter window
"FanCoil cooling"

General	Stage limit in night mode	No limit
Temperature measurement	Automatic return from manual adjustment (0 - inactive, min)	0
Controller general	Return inactive a fan stage off and automatic return not 0	☒ Yes ☐ No
Heating control	Threshold value stage 1	10
Cooling control	Threshold value stage 2	40
Setpoint general	Threshold value stage 3	70
Manual setpoint		
Setpoints heat/cool		
FanCoil general		
FanCoil heating		
FanCoil cooling		

Step limit in night mode

- Options:
- No limit
 - Fan Off
 - Stage 1
 - Stage 2

If the device is used in an environment such as a hotel room, it may be desirable to limit the fan stages during the night to reduce the noise. The parameter "Step limit in night mode" is used for this. If the parameter is set to stage 1, the fan will not use more that the first stage when night mode is enabled. This will apply even if the transmitted control value requests a higher fan stage.

Automatic return from manual adjustment (0 - inactive, min)

- Options:
- 0 / 1 / 2 / ... / 60

If "Manual stage switching" was performed by the user, this action can be reset via onsite operation of the ambient temperature controller. However, a time can also be input after which the ambient temperature cancels the "Manual stage switching" and switches back to automatic stage switching mode.

This parameter is only available if the "Cooling" or "Heat and cool" control functions are used and the cooling control type is set to "FanCoil".

Return inactive a fan stage off and automatic return not 0

Options: - **Yes**
 - No

If the user has manually changed the stage to "Switch off", the ambient temperature controller can also be set so that it does not return to automatic switching at the end of the "Manual switching period" but rather remains switched off.

This parameter is only available if the "Cooling" or "Heat and cool" control functions are used and the cooling control type is set to "FanCoil".

Threshold value stage 1

Options: - 0%
 - **10 %**
 - ...
 - 50 %
 - ...
 - 100 %

Threshold value stage 1 specifies the magnitude of the control value required to switch the ambient temperature controller to fan stage 1. The threshold can be defined in percentages. Make sure that the threshold for stage 1 is not set higher than the threshold for stage 2 (if available). This parameter is only available if the "Cooling" or "Heat and cool" control functions are used, the heating control type is set to "FanCoil" and the number of fan stages is min. "1 stage".

Threshold value stage 2

Options: - 0%
 - 10 %
 - ...
 - **40 %**
 - ...
 - 100 %

Threshold value stage 2 specifies the magnitude of the control value required to switch the ambient temperature controller from fan stage 1 to fan stage 2. The threshold can be defined in percentages. Make sure that the threshold for stage 2 is not set higher than the threshold for stage 3 (if available).

This parameter is only available if the "Cooling" or "Heat and cool" control functions are used, the cooling control type is set to "FanCoil" and the number of fan stages is min. "2 stages".

Threshold value stage 3

- Options:
- 0%
 - 10 %
 - ...
 - **70 %**
 - ...
 - 100 %

Threshold value stage 3 specifies the magnitude of the control value required to switch the ambient temperature controller from fan stage 2 to fan stage 3. The threshold can be defined in percentages. Make sure that the threshold for stage 3 is not set higher than the threshold for stage 3 (if available).

This parameter is only available if the "Cooling" or "Heat and cool" control functions are used, the heating control type is set to "FanCoil" and the number of fan stages is min. "3 stages".

3.2.16 Parameter window "Compensation"

General	Summer compensation active	☒ Yes ☐ No
Temperature measurement	Summer compensation lower exterior temp. value	20 °C
Controller general	Summer compensation upper exterior temp. value	32 °C
Heating control	Summer compensation lower setpoint offset	0 K
Cooling control	Summer compensation upper setpoint offset	4 K
Setpoint general	Winter compensation active	☒ Yes ☐ No
Manual setpoint	Winter compensation lower exterior temp. value	0 °C
Setpoints heat/cool	Winter compensation upper exterior temp. value	10 °C
FanCoil general	Winter compensation lower setpoint offset	4 K
FanCoil heating	Winter compensation upper setpoint offset	0 K
FanCoil cooling		
Compensation		
Relative humidity general		

Summer compensation active

Options: - Yes
 - No

To save energy and to maintain a reasonable temperature differential when entering an air-conditioned building, you should adjust the room temperature in relation to external temperature (summer compensation).

Raising the room temperature does not, however, mean that you heat up the room. Rather the adjustment is intended to allow the room temperature without cooling to increase to a specified value. This prevents an air-conditioner from continuing to try to reduce the ambient temperature to 24 °C at an outside temperature of 35 °C. This function can only be used together with an external temperature sensor. If no external temperature sensor is in use, set the parameter to "No".

CO is shown in the display when compensation is enabled.

Summer compensation lower exterior temp. value

Options: - 9 °C
 - 10 °C
 - ...
 - **20°C**
 - ...
 - 31: 40°C

This specifies the lower outside temperature from which compensation should be enabled because of a high outside temperature.

Summer compensation upper exterior temp. value

- Options:
- 9 °C
 - 10 °C
 - ...
 - **32°C**
 - ...
 - 31: 40°C

This specifies the upper outside temperature from which compensation should be enabled because of a high outside temperature.

Summer compensation lower setpoint offset

- Options:
- **0 K**
 - 1 K
 - 2 K
 - ...
 - 10 K

The "lower setpoint offset" specifies how many K the setpoint should be increased during summer compensation if the "lower exterior temperature" is reached.

Typical values for summer compensation are

- 20 °C: lower outside temperature
- 32 °C: upper outside temperature
- 0 K: lower setpoint offset
- 4 K: upper setpoint offset

This means that a floating setpoint increase from 0 to 4 K will be implemented if the outside temperature increases from 20 °C to 32 °C.

Summer compensation upper setpoint offset

- Options:
- 0 K
 - 1 K
 - 2 K
 - ...
 - **4 K**
 - ...
 - 10 K

The "upper setpoint offset" specifies how many K the setpoint should be increased during summer compensation if the "upper exterior temperature" is reached.

Typical values for summer compensation are

- 20 °C: lower outside temperature
- 32 °C: upper outside temperature
- 0 K: lower setpoint offset
- 4 K: upper setpoint offset

This means that a floating setpoint increase from 0 to 4 K will be implemented if the outside temperature increases from 20 °C to 32 °C.

Winter compensation active

Options: - Yes
 - **No**

To improve comfort and to maintain a reasonable temperature differential when entering a room with a large window area, you should increase the room temperature depending on the outside temperature in winter (winter compensation).

This function can only be used together with an external temperature sensor. If no external temperature sensor is in use, set the parameter to "No".

CO is shown in the display when compensation is enabled.

Winter compensation lower exterior temp. value

Options: - -10 °C
 - -9 °C
 - ...
 - **0 °C**
 - ...
 - 21 °C

This specifies the lower outside temperature up to which the setpoint should be corrected (winter compensation) because of an excessively low outside temperature.

Winter compensation upper exterior temp. value

Options: - -10 °C
 - -9 °C
 - ...
 - **10 °C**
 - ...
 - 21 °C

This specifies the upper outside temperature from which the setpoint should be corrected (winter compensation) because of an excessively low outside temperature.

SATION KNX Commissioning

Winter compensation lower setpoint offset

- Options:
- 0 K
 - 1 K
 - 2 K
 - ...
 - **4 K**
 - ...
 - 10 K

The "lower setpoint offset" specifies how many K the setpoint should be increased during winter compensation if the "lower exterior temperature" is reached.

Typical values for winter compensation are

- 0 °C: lower outside temperature
- 10 °C: upper outside temperature
- 4 K: lower setpoint offset
- 0 K: upper setpoint offset

This means that a floating setpoint increase from 0 to 4 K will be implemented if the outside temperature falls from 10 °C to 0 °C.

Winter compensation upper setpoint offset

- Options:
- **0 K**
 - 1 K
 - 2 K
 - ...
 - 10 K

The "upper setpoint offset" specifies how many K the setpoint should be increased during winter compensation if the "upper exterior temperature" is reached.

Typical values for winter compensation are

- 0 °C: lower outside temperature
- 10 °C: upper outside temperature
- 4 K: lower setpoint offset
- 0 K: upper setpoint offset

This means that a floating setpoint increase from 0 to 4 K will be implemented if the outside temperature falls from 10 °C to 0 °C.

SATION KNX Commissioning

3.2.17 Parameter window "Valve Heating — 3-position, opening and closing "

General	Valve control	☐ 2-position,PWM ☒ 3-position,opening and closing
Temperature measurement	Observe reversing time	100 ms
Controller general	Valve control duration from 0 to 100% in s [10...6,000]	10
Heating control	Automatically adjust valve position	☐ no ☒ yes
Cooling control	Number of valve controls up to adjustment [1...65,535]	100
Setpoint general	Enable valve purge	☐ no ☒ yes
Manual setpoint	Enable communication object "Status valve purge" 1 bit	☐ no ☒ yes
Setpoints heat/cool	Send object value	after a change
FanCoil general	Duration of valve purge in min. [1...255]	10
FanCoil heating		
FanCoil cooling		
Compensation		
Valve Heating		
Valve Cooling		
Buttons for Switching Group		

Valve control

Options: 2-position, PWM
3-position, opening and closing

With this parameter, the properties of the connected valve are set.

Observe reversing time

Options: no
100/300/500/700/1,000 ms

A reversing time pause is set via this parameter.

The time should be taken from the technical data of the valve.

Valve control

**duration from 0 to 100 %
in s [10...6,000]**

Option: 10...180...6,000

With this parameter, a time is set in seconds that the connected valve requires to move from position 0 % (valve closed) to position 100 % (valve fully open).

Note

The time should be taken from the technical data of the valve.

SATION KNX Commissioning

Automatically adjust valve position

Option: no
yes

no: Nothing happens.

yes: A further parameter appears:

Note
A manual triggering of the adjustment is not possible!

Adjust with control value 0 %

Any action with control value 0 % is executed as an adjustment, i.e.:

- The valve is fully closed regardless of the curve.
- The closing position is exceeded by 5 % of the total time, max. one minute.
- This function cannot be interrupted!
- Thereafter, the current valve position is approached, and the adjustment counter is set to 0.

The following applies with automatic adjustment

- The adjustment counter is incremented by 1 every time the valve stops.
- If the parameterized limit of the adjustment counter is exceeded in the closing direction, the adjustment starts.
- If higher priorities are activated at the time of automatic adjustment, the adjustment will be performed later.
- The adjustment is interrupted by higher priority events.
- The valve is fully closed regardless of the curve.
- The closing position is exceeded by 5 % of the total time, max. one minute. This function cannot be interrupted! Thereafter, the current valve position is approached, and the adjustment counter is set to 0.

Note
A valve adjustment has occurred if a control of the drive has actually been undertaken. If priorities and curves prevent this, the adjustment counter will not change.

SATION KNX Commissioning

Reference movement

A referencing or homing run can be understood as a complete closing of the valve.

Referencing is undertaken after:

- Every reset of the bus.
- A change of version.
- Every reset of an un-parameterized device
- A download with modified adjustmenttime.

The following should be considered:

- Referencing cannot be interrupted.
- The closing position is exceeded by 5 % of the total time, max. one minute.
- After the reference movement, the current valve position is moved to and the adjustment counter is set to 0.

Number of valve controls up to adjustment [1...65,535]

Option: 1...100...65,535

With this parameter, the number of operations (valve controls), after which automatic adjustment is undertaken, can be set.

Note
All actions greater than zero (motor does not move) are counted. The number should be taken from the technical data of the valve manufacturer.

Enable valve purge

Options: no
yes

- yes: The 1 bit communication object *Trigger valve purge* is enabled. The following parameters appear:

Note
If the valve purge is interrupted by a higher priority, it will restart after the completion of the priority task, unless, for example, the control value was 100 % or it was active for the duration of the purge time due to the higher priority. The valve position for purging is always the control value 100 %.

Enable communication object "Status valve purge" 1 bit

Options: no
yes

- yes: The 1 bit communication object *Status valve purge* is enabled.

The status of the valve purge is visible via this communication object. The following parameter appears:

SATION KNX Commissioning

Send object value

Options: no, update only
 After a change
 after request
 after a change or request

- *no, update only*: The status is updated but not sent.
- *after a change*: The status is sent after a change.
- *after request*: The status is sent after a request.
- *after a change or request*: The status is sent after a change or a request.

Note
The status is sent immediately as soon as a new control value is received.

Duration of valve purge in min.

[1...255]

Options: 1...10...255

This parameter defines the time duration for the valve purge. In this time, the valve is fully opened. When the time has elapsed, the state before the purge is re-established.

Note
The opening time of the valve must be considered when entering the purge time.

SATION KNX Commissioning

3.2.18 Parameter window “Valve Heating — 2-position, PWM”

General	Valve control	☒ 2-position,PWM ☐ 3-position,opening and closing
Temperature measurement	Valve type	☒ de-energised closed ☐ de-energised opened
Controller general	Cycle time of the PWM in s [10...6,000]	120
Heating control	Valve control duration from 0 to 100% in s [10...6,000]	10
Cooling control	Valve control duration from 100 to 0% in s [10...6,000]	10
Setpoint general	Enable valve purge	☐ no ☒ yes
Manual setpoint	Enable communication object "Status valve purge" 1 bit	☐ no ☒ yes
Setpoints heat/cool	Send object value	after a change
FanCoil general	Duration of valve purge in min. [1...255]	10
FanCoil heating		
FanCoil cooling		
Compensation		

Valve Heating

Valve Cooling

Buttons for Switching Group

Valve type

Options: de-energised closed
de-energised opened

Using this parameter the valve type for the connected valve is set.

How does a de-energised closed (normally closed) valve behave?

If no current flows in the control circuit the valve is closed.

The valve is opened as soon as current flows in the control circuit.

How does a de-energised opened (normally open) valve behave?

If no current flows in the control circuit the valve is opened.

The valve is closed as soon as current flows in the control circuit.

SATION KNX Commissioning

Cycle time of the PWM in s
[10...6,000]

Option: 10...120...6,000

This is used to set the cycle time of the PWM control.

Important
The minimum pulse length is defined as 0.5 seconds, so that with very short cycle times (< 1 min.), there are very short switch on times (with small percentage values) or switch off times (with higher percentage values).

Valve control duration from 0 to 100 % in s
[10...6,000]

Option: 10...180...6,000

With this parameter, a time is set in seconds that the connected valve requires to move from position 0 % (valve closed) to position 100 % (valve fully open).

Note
The time should be taken from the technical data of the valve and corresponds with the total runtime.

Valve control duration from 100 to 0 % in s
[10...6,000]

Option: 10...180...6,000

With this parameter, a time is set in seconds that the connected valve requires to move from position 100% (valve open) to position 0 % (valve fully closed).

Note
The time should be taken from the technical data of the valve and corresponds with the total runtime.

Parameter window *Valve COOLING*

The setting options of *Valve COOLING* do not differentiate from those of *Valve HEATING*.

The descriptions of the parameter setting options and adjustable communication objects for the *valve COOLING* are described under [Parameter window Valve HEATING–3-point, opening and closing.](#)

SATION KNX Commissioning

3.2.19 Parameter window “Buttons for Switching Group”

General	Function buttons	Switch
Temperature measurement	On/Off function	☐ Top: On / Bottom: Off ☒ Twice On / Off
Controller general	Function button top	Toggle
Heating control	Function button bottom	Toggle
Cooling control		
Setpoint general		
Manual setpoint		
Setpoints heat/cool		
FanCoil general		
FanCoil heating		
FanCoil cooling		
Compensation		
Valve Heating		
Valve Cooling		
Buttons for Switching Group		

Function buttons

- Options:
- Not used
 - Switch
 - Dim
 - Blind
 - Scene

This parameter defines four function buttons, which are Switch, Dimming, Blind and Scene.

- **Switch:**

- Options:
- Top: On / Bottom: Off
 - Twice On / Off

- **Twice On / Off:** The following parameter appears:

- **Function button top:**

- Options:
- Toggle
 - On
 - Off

- **Function button bottom:**

- Options:
- Toggle
 - On
 - Off

- **Dim:**
- **Blind:**

SATION KNX Commissioning

- **Scene:**

- Scene number button top**

- Option: 1.....64

- Scene number button bottom**

- Option: 1.....64

SATION KNX Commissioning

3.3 Communication objects

3.3.1 General

Number	Name	Object Function	Length	C	R	W	T	U
0	In Operation	General	1 bit	C	-	-	T	-
1	General	Unit On/Off	1 bit	C	R	W	T	-
2	General	Switch °C/°F display unit	1 bit	C	R	W	-	-
3	General	Illumination On/Off	1 bit	C	-	W	-	-

No.	Function	Object name	Data type	Flags
0	In Operation	General	1 Bit EIS1 DPT 1.001	C, T
<p>Sends the object value "0" or "1" to the bus cyclically. Object value and cycle time can be set in the parameters.</p> <p>The telegram can be used for life-beat monitoring of the device, e.g. by a monitoring block.</p>				
1	Unit On/Off	General	1 Bit EIS1 DPT 1.001	C, R, W, T
<p>The controller is activated via this 1-bit communication object when an ON telegram is received and deactivated when an OFF telegram is received. It can receive and send, Switching the controller on and off is the same as actuating the ON/OFF switch on the device.</p> <p>When the device is switched off OFF is shown on the display, but the controller setpoint is switched to a parameterisable temperature setpoint and the fan switches off immediately.</p> <p>0: switch off device or device is switched off 1: switch on device or device is switched on</p>				
2	Switch °C/°F display unit	General	1 bit EIS1 DPT 1.001	C, R, W
<p>This 1-bit communication object can be used to switch the units display between °C and °F. If the object receives an ON telegram the display switches to °F. If an OFF telegram is received the display changes to °C.</p> <p>This data item forms the 1-bit KNX object and can be sent and received.</p> <p>The communication object is always visible.</p> <p>0: display in °C 1: display in °F</p>				
3	Illumination On/Off	General	1 Bit EIS1 DPT 1.001	C, W
<p>The object enables switching the display lighting on and off via the bus.</p> <p>0: lighting Off 1: lighting On</p> <p>Note: Automatic mode is enabled after receipt of an OFF telegram.</p>				

SATION KNX Commissioning

3.3.2 Control system

Number	Name	Object Function	Length	C	R	W	T	U
4	Control	Frost/heat protection	1 bit	C	R	W	-	-
5	Control	Activate night mode	1 bit	C	R	W	-	-
6	Control	User absent	1 bit	C	R	W	T	-

No.	Function	Object name	Data type	Flags
4	Frost/heat protection	Control	1 Bit EIS1 DPT 1.001	C, R, W
<p>This data item forms the 1-bit object of KNX for switching operating modes (frost and heat protection). It can be received only.</p> <p>For example, binary inputs that record information from window contacts to notify the ambient temperature controller that a window is open or closed can send their current status to the frost and heat protection object. When receiving an ON telegram, the room thermostat activates frost protection mode; when an OFF telegram is received, frost protection mode is deactivated and the current mode is changed.</p> <p>The "window" symbol is shown in the display when frost/heat protection is enabled.</p> <p>0: Frost/Heat Protection Off 1: Frost/Heat Protection On</p>				
5	Activate night mode	Control	1 Bit EIS1 DPT 1.001	C, R, W
<p>This 1-bit communication object can be used to switch the room thermostat to night mode when an ON telegram is received. An OFF telegram deactivates night mode. This communication object can be used, e.g., by time switches to send information.</p> <p>This data item forms the 1-bit object of KNX for switching operating modes (night mode). It can be received only, because a manual switch to night mode on site is not possible.</p> <p>In night mode the parameterisable setpoint "night mode" is enabled and the fan stage is limited to a parameterisable value.</p> <p>0: night mode Off 1: night mode On</p>				
6	User absent	Control	1 Bit EIS1 DPT 1.001	C, R, W, T
<p>This 1-bit communication object switches the room thermostat between comfort and standby modes. When an ON telegram is received, comfort mode is activated; when an OFF telegram is received, standby mode is activated.</p> <p>This data item forms the 1-bit object of KNX for switching operating modes (comfort / standby). It can be received and sent.</p> <p>0: control system is in Standby mode 1: control system is in Comfort mode</p>				

SATION KNX Commissioning

Number	Name	Object Function	Length	C	R	W	T	U
7	Control	Operating mode switchover	1 Byte	C	R	W	T	-
8	Control	Operating mode switchover required	1 Byte	C	R	W	-	-

No.	Function	Object name	Data type	Flags
7	Operating mode switchover	Control	1 byte DPT_HVAC Mode	C, R, W, T

This data item forms the 1-bit object of KNX (DPT_HVAC_MODE) for switching operating modes. All operating modes of the above 1-bit objects can be set with the 1-byte object. The data item can be received and sent. The selection of whether switching is via three 1-bit objects or two 1-byte objects (OMN / OMO) is defined by application parameters (see above).

This 1-byte communication object can be used to switch between comfort, standby, night and frost/heat protection modes. The object evaluates received telegrams as "normal". This means, for example, if a comfort telegram is received, the room thermostat switches to comfort mode. If a night telegram is received, the room thermostat switches to night mode. This object is controlled, for example, by time switches.

The following provisions apply for the object:

- 0: Auto
- 1: Comfort
- 2: Standby
- 3: Night
- 4: Frost/Heat Protection
- 5 – 255: not permitted

8	Operating mode switchover required	Control	1 byte DPT_HVAC Mode	C, R, W
---	---	----------------	-------------------------------------	----------------

This data item corresponds to the **operating mode switching 1 byte** function, where it overrides the OMN (Operation Mode Normal vs. Operation Mode Overwrite).

This 1-byte communication object can temporarily "overwrite" the previous 1-byte mode object. This means, for example, if a frost/heat protection telegram is received, the ambient temperature controller switches to frost or heat protection mode. If the frost or heat protection is reset by the receipt of another telegram, the ambient temperature controller enables the operating mode on the "normal" 1-byte operating mode object. As a result, it is capable of noting operating modes. This object is controlled, for example, by binary inputs that record information from window contacts.

The following provisions apply for the object:

- 0 = Auto
- 1 = Comfort
- 2 = Standby
- 3 = Night
- 4 = Freezing/Heat Protection
- 5 – 255 = not permitted

SATION KNX Commissioning

Number	Name	Object Function	Length	C	R	W	T	U
9	Temperature sensor	Send setpoint	2 Byte	C	R	-	T	-
10	Temperature recording	Input current exterior temperature	2 Byte	C	-	W	-	-
11	Temperature recording	Input exterior temperature	2 Byte	C	-	W	-	-

No.	Function	Object name	Data type	Flags
9	Send setpoint	Temperature sensor	2 byte	C, R, T
<p>This data item forms the 2-byte object of KNX for the current temperature. The temperature is measured in the "temperature sensor" application and can be weighted with an external input temperature (object <i>input for external current temperature</i>). It can be sent only.</p> <p>Must be cyclic and be able to send on change.</p>				
10	Input current exterior temperature	Temperature recording	2 byte	C, W
<p>A temperature value from an additional sensor can be received via this 2-byte communication object. By parameterising the controller properly, the received value can also be included in the controller and weighted, if necessary.</p> <p>This data item forms the 2-byte object of KNX for the current external temperature. It can be received only.</p>				
11	Input exterior temperature	Temperature recording	2 byte	C, W
<p>This data item forms the 2-byte object of KNX for outside temperature recording. It can be received only. This object is relevant for summer and winter compensation (summer compensation in accordance with DIN 1946). The temperature from which the summer or winter compensation is applied can be adjusted by application parameters (see above).</p> <p>Behaviour with setpoint adjustment by user:</p> <p>The adjust setpoint is displayed to the user. The permitted adjustment range is moved accordingly.</p>				

SATION KNX Commissioning

3.3.3 Setpoints

Number	Name	Object Function	Length	C	R	W	T	U
12	Control	Current setpoint cooling	2 Byte	C	R	W	T	-
13	Control	Current setpoint heating	2 Byte	C	R	W	T	-
14	Control	Base setpoint	2 Byte	C	R	W	-	-
23	Control	Reset of local operation	1 bit	C	-	W	-	-

(Dependent setpoints)

Number	Name	Object Function	Length	C	R	W	T	U
12	Control	Current setpoint cooling	2 Byte	C	R	W	T	-
13	Control	Current setpoint heating	2 Byte	C	R	W	T	-
15	Control	Heating setpoint comfort	2 Byte	C	R	W	-	-
16	Control	Heating setpoint standby	2 Byte	C	R	W	-	-
17	Control	Heating setpoint night mode	2 Byte	C	R	W	-	-
18	Control	Setpoint frost protection	2 Byte	C	R	W	-	-
19	Control	Cooling setpoint comfort	2 Byte	C	R	W	-	-
20	Control	Cooling setpoint standby	2 Byte	C	R	W	-	-
21	Control	Cooling setpoint night mode	2 Byte	C	R	W	-	-
22	Control	Setpoint heat protection	2 Byte	C	R	W	-	-
23	Control	Reset of local operation	1 bit	C	-	W	-	-

(Individual setpoints)

No.	Function	Object name	Data type	Flags
12	Current setpoint cooling	Control	2 byte	C, R, W, T
<p>This data item forms the 2-byte KNX object and can be sent and received. It is relevant for setpoint management and for calibration of setpoint offsets between devices.</p> <p>This object is used for displaying the current setpoint, e.g. for display and diagnostics.</p>				
13	Current setpoint heating	Control	2 byte	C, R, W, T
<p>This data item forms the 2-byte KNX object and can be sent and received. It is relevant for setpoint management and for calibration of setpoint offsets between devices.</p> <p>This object is used for displaying the current setpoint, e.g. for display and diagnostics.</p>				
14	Base setpoint	Control	2 byte	C, R, W
<p>Object is visible if the dependent setpoint preset has been set in the parameters.</p> <p>This data item forms the 2-byte base setpoint KNX object and can be received. It is relevant for the concept of the dependent setpoint adjustment and is not used with absolute setpoints.</p> <p>It can also be used to reset the manual on-site adjustment if this function is parameterised.</p> <p>The setpoint is qualified via application parameters if "heating and cooling" is selected.</p> <p>The base setpoint can then be defined as BSW heating, BSW cooling or centre of dead zone.</p> <p>If only heating or only cooling is enabled, the BSP corresponds to the selected operating mode.</p>				
15	Heating setpoint comfort	Control	2 byte	C, R, W
<p>Object is visible if the individual setpoint preset has been set in the parameters.</p> <p>This data item forms the 2-byte KNX object and can be received. It is relevant for absolute setpoint management. When a setpoint for an operating mode is received, the corresponding setpoint is automatically enabled.</p>				
16	Heating setpoint standby	Control	2 byte	C, R, W
<p>Object is visible if the individual setpoint preset has been set in the parameters.</p> <p>This data item forms the 2-byte KNX object and can be received. It is relevant for absolute setpoint management. When a setpoint for an operating mode is received, the corresponding setpoint is automatically enabled.</p>				

SATION KNX Commissioning

17	Heating setpoint night mode	Control	2 byte	C, R, W
<p>Object is visible if the individual setpoint preset has been set in the parameters.</p> <p>This data item forms the 2-byte KNX object and can be received. It is relevant for absolute setpoint management. When a setpoint for an operating mode is received, the corresponding setpoint is automatically enabled.</p>				
18	Setpoint frost protection	Control	2 byte	C, R, W
<p>Object is always visible if the individual setpoint preset has been set in the parameters.</p> <p>This data item forms the 2-byte KNX object and can be received. It is relevant for absolute and relative setpoint management. When a setpoint for an operating mode is received, the corresponding setpoint is automatically enabled.</p>				
19	Cooling setpoint comfort	Control	2 byte	C, R, W
<p>Object is visible if the individual setpoint preset has been set in the parameters.</p> <p>This data item forms the 2-byte KNX object and can be received. It is relevant for absolute setpoint management. When a setpoint for an operating mode is received, the corresponding setpoint is automatically enabled.</p>				
20	Cooling setpoint standby	Control	2 byte	C, R, W
<p>Object is visible if the individual setpoint preset has been set in the parameters.</p> <p>This data item forms the 2-byte KNX object and can be received. It is relevant for absolute setpoint management. When a setpoint for an operating mode is received, the corresponding setpoint is automatically enabled.</p>				
21	Cooling setpoint night mode	Control	2 byte	C, R, W
<p>Object is visible if the individual setpoint preset has been set in the parameters.</p> <p>This data item forms the 2-byte KNX object and can be received. It is relevant for absolute setpoint management. When a setpoint for an operating mode is received, the corresponding setpoint is automatically enabled.</p>				
22	Setpoint heat protection	Control	2 byte	C, R, W
<p>Object is always visible if the individual setpoint preset has been set in the parameters.</p> <p>This data item forms the 2-byte KNX object and can be received. It is relevant for absolute and relative setpoint management. When a setpoint for an operating mode is received, the corresponding setpoint is automatically enabled.</p> <p>Value 99.9 means heat protection = off.</p>				
23	Reset of local operation	Control	1 Bit EIS1 DPT 1.001	C, W
<p>This 1-bit communication object is enabled, if the proper parameter has been set to "yes".</p> <p>This object resets the comfort setpoint to the parameterised value.</p> <p>This data item forms the 1-byte KNX object and can be received only. Manual operation is reset when a "1" is received.</p>				

SATION KNX Commissioning

3.3.4 Control value

Number	Name	Object Function	Length	C	R	W	T	U
24	Control value	Control value heating	1 bit	C	R	-	T	-
25	Control value	Control value cooling	1 bit	C	R	-	T	-
26	Control value	Contr. value add. heat. stage	1 bit	C	R	-	T	-
27	Control value	Contr. value add. cool. stage	1 bit	C	R	-	T	-
28	Control value	Status heat requirement	1 bit	C	-	W	-	-
29	Control value	Status cooling requirement	1 bit	C	R	-	T	-

No.	Function	Object name	Data type	Flags
24	Control value heating	Control value	1 byte / 1 bit	C, R, T
2 channel (4-pipe system) This data item forms the 1-byte or 1-bit KNX object and can be sent only. This object is the control value for heating. In fan coil systems with only one output channel it is the "heating/cooling" object in which the internal allocation is controlled by the external operating mode switching (see index 6). When acting as a branch the control value is received via this object.				
25	Control value cooling	Control value	1 byte / 1 bit	C, R, T
This data item forms the 1-byte or 1-bit KNX object and can be sent only. This object is the control value for cooling. This object is used with 2 channels (4-pipe system) only. When acting as a branch the control value is received via this object.				
26	Contr. value add. heat. stage	Control value	1 byte / 1 bit	C, R, T
This data item forms the 1-byte or 1-bit KNX object and can be sent only. This object is the control value for the heating additional stage (switching or quasi continuous).				
27	Contr. value add. cool. stage	Control value	1 byte / 1 bit	C, R, T
This data item forms the 1-byte or 1-bit KNX object and can be sent only. This object is the control value for the cooling additional stage (switching or quasi continuous).				
28	Status heat requirement	Control value	1 bit	C, W
This data item acts as an output and provides information on whether the cooling output is currently enabled (including in the switched-off phases of a PWM cycle). This information can be useful for visualisation.				
29	Status cooling requirement	Control value	1 bit	C, R, T
This data item acts as an output and provides information on whether the cooling output is currently enabled (including in the switched-off phases of a PWM cycle). This information can be useful for visualisation.				

SATION KNX Commissioning

3.3.5 Heating / cooling

Number	Name	Object Function	Length	C	R	W	T	U
30	Heat/Cool	Heat/cool switchover	1 bit	C	R	W	T	-

No.	Function	Object name	Data type	Flags
24	Control value heating	Control value	1 byte / 1 bit	C, R, T

1 channel (2-pipe system)

This data item forms the 1-byte or 1-bit KNX object and can be sent only. This object is the control value for heating and cooling. In fan coil systems with only one output channel it is the "heating/cooling" object in which the internal allocation is controlled by the external operating mode switching (see index 6).

When acting as a branch the control value is received via this object.

30	Heat/Cool switchover	Heat/Cool	1 Bit EIS1 DPT 1.001	C, R, W, T
----	----------------------	-----------	-------------------------	---------------

This data item forms the 1-bit KNX object. It can be received and sent. If the RTR switches the operating mode, the object is sent if the corresponding parameter has been set to "automatic and send". In the event of external switching the operating mode is switched by a different bus device (such as a fan coil 2-line system). After the switching a separate output object or the same output object can be used (depending on the number of output channels with "heating and cooling").

0: cooling
1: heating

SATION KNX Commissioning

3.3.6 Fan automatic / manual

Number	Name	Object Function	Length	C	R	W	T	U
31	Fan automatic / manual	Automatic On/Off	1 bit	C	R	W	T	-
32	Fan manual	Fan stage manual 1 byte	1 Byte	C	R	W	T	-
33	Status FanCoil operation	Status operating state of FanCoil	1 Byte	C	-	W	-	-

No.	Function	Object name	Data type	Flags
31	Automatic on/off	Fan automatic / manual	1 Bit EIS1 DPT 1.001	C, R, W, T
<p>If a fan coil actuator is tripped by the ambient temperature controller, the individual fan stages are typically switched automatically by the room thermostat. However, users can select a stage manually. When the stage is specified manually, the 1-bit communication object triggers an ON telegram and when manual mode is deactivated, an OFF telegram is sent. This enables you to notify a second control unit that a stage has been set manually.</p> <p>The 1-bit object can also receive and analyse telegrams sent from other control points.</p> <p>This data item forms the 1-bit KNX object and can be sent and received. When switching to manual operation and sending a fan stage via the display, manual mode is enabled. Automatic mode is re-enabled with this data item after automatic return after a parameterisable time. For example, if an automatic return is not to be parameterised, the RTR can be reset externally to the controlling operation via this object.</p> <p>Note: the coding of this object is matched to actuators. A link to other manufacturers may make it necessary to use the alternative object "manual switching on/off".</p> <p>0: the user must set the fan stage (0-3) manually. 1: the fan stage is set to "auto"</p>				
31	Manual on/off	Fan automatic / manual	1 bit	C, R, W, T
<p>See description of "Automatic switching on/off"</p> <p>The object is visible if it is enabled in the parameters.</p> <p>0: the fan stage is set to "auto" 1: the user must set the fan stage (0-3) manually.</p>				
No.	Function	Object name	Data type	Flags
32	Fan stage manual 1 byte	Fan manual	1 byte	C, R, W, T
<p>The object is visible alternatively to 1-bit objects 34-36.</p> <p>The device sets the fan stage actuator to manual mode with this object.</p> <p>The object has two possible codings, which can be set alternately in the parameters.</p> <p>Coding 1: 1 byte continuous value (0...100%) Coding 2: 1 byte counter value, value range 0...3</p>				
33	Status operating state of FanCoil	Status FanCoil operation	1 byte	C, W
<p>This 1-byte communication object can be used by the room thermostat to receive information about the status of the fan coil actuator. It can evaluate whether stage 1, 2, 3, etc. or no stage was activated.</p>				

SATION KNX Commissioning

Number	Name	Object Function	Length	C	R	W	T	U
31	Fan automatic / manual	Automatic On/Off	1 bit	C	R	W	T	-

Nummer	Funktion	Name	Länge	K	L	S	Ü	A
31	Manuell Ein/Ausschalten	Lüfter Automatik / Manuell	1 bit	K	L	S	Ü	A
34	FanCoil Stufe 1 schalten	Lüfter Manuell	1 bit	K	L	S	Ü	A
35	FanCoil Stufe 2 schalten	Lüfter Manuell	1 bit	K	L	S	Ü	A
36	FanCoil Stufe 3 schalten	Lüfter Manuell	1 bit	K	L	S	Ü	A

No.	Function	Object name	Data type	Flags
34	Switch fan coil stage 1	Fan manual	1 Bit EIS1 DPT 1.001	C, R, W, T
<p>This 1-bit communication object can be used to send an ON telegram, if the first fan stage is to be switched on. An OFF telegram is sent, if the first fan stage is no longer to be switched on.</p> <p>This data item forms the 1-bit KNX object and can be sent and received.</p>				
35	Switch fan coil stage 2	Fan manual	1 Bit EIS1 DPT 1.001	C, R, W, T
<p>This 1-bit communication object can be used to send an ON telegram, if the second fan stage is to be switched on. An OFF telegram is sent, if the third fan stage is no longer to be switched on.</p> <p>This data item forms the 1-bit KNX object and can be sent and received.</p>				
36	Switch fan coil stage 3	Fan manual	1 Bit EIS1 DPT 1.001	C, R, W, T
<p>This 1-bit communication object can be used to send an ON telegram, if the third fan stage is to be switched on. An OFF telegram is sent, if the third fan stage is no longer to be switched on.</p> <p>This data item forms the 1-bit KNX object and can be sent and received.</p>				

SATION KNX Commissioning

3.3.7 Monitoring

Number	Name	Object Function	Length	C	R	W	T	U
37	Actuator monitoring	Receive in operation	1 bit	C	-	W	-	-
39	Dew-point monitoring	Signal dew point	1 bit	C	-	W	-	-
40	Monitoring of condensate tank	Signal condensate tank	1 bit	C	-	W	-	-

No.	Function	Object name	Data type	Flags
37	Receive in operation	Actuator monitoring	1 bit	C, W
<p>The object is visible if the corresponding parameter is set to "yes".</p> <p>This object monitors the cyclic sending of the actuator "In use" communication object. If monitoring is triggered, the "fault" symbol (plus text display) is shown on the display (it disappears automatically).</p>				
39	Signal dew point	Dew-point monitoring	1 Bit EIS1 DPT 1.001	C, W
<p>This 1-bit communication object should be used to send telegrams from a dew point sensor that, for example, is connected to a binary input. If the object receives an ON telegram, heat protection is enabled; if the object receives an OFF telegram, heat protection is disabled.</p> <p>This data item forms the 1-byte KNX object and can be received only. The action depends on the parameterisation.</p>				
40	Signal condensate tank	Monitoring of condensate tank	1 Bit EIS1 DPT 1.001	C, W
<p>This 1-bit communication object should be used to send telegrams from a dew point sensor that, for example, is connected to a binary input. If the object receives an ON telegram, heat protection is enabled; if the object receives an OFF telegram, heat protection is disabled.</p> <p>This data item forms the 1-byte KNX object and can be received only. The action depends on the parameterisation.</p>				

SATION KNX Commissioning

3.3.8 Alarm temperature

Number	Name	Object Function	Length	C	R	W	T	U
41	Alarm temperature	Report failure of current temp.	1 bit	C	R	-	T	-
42	Alarm temperature	Report failure of ext. temp.	1 bit	C	R	-	T	-

No.	Function	Object name	Data type	Flags
41	Report failure of current temp	Alarm temperature	1 Bit EIS1 DPT 1.001	C, R, T
This data item forms the 1-bit KNX object and can be sent only. It is sent if there is no more CURRENT temperature measurement and the correct control system is in danger as a result.				
42	Report failure of ext. temp.	Alarm temperature	1 Bit EIS1 DPT 1.001	C, R, T
<p>The refers to object 11 "External temperature input - temperature recording".</p> <p>This data item forms the 1-bit KNX object and can be sent only. It is sent if there is no more CURRENT temperature measurement and the correct control system is in danger as a result.</p>				

SATION KNX Commissioning

3.3.9 Status byte

Nu...	Name	Object Function	Length	C	R	W	T	U
44	Status byte	Status byte HVAC status	1 Byte	C	R	-	T	-
43	Status byte	Status byte RHCC status	2 Byte	C	R	-	T	-

No.	Function	Object name	Data type	Flags
43	Status byte RHCC status	Status byte	2 byte DPT 22.101	C, R, T
KNX status byte DPT 22.101 Bit 0 failure message of CURRENT temperature recording Coding: 0 no fault in CURRENT temperature recording Coding: 1 fault in CURRENT temperature recording Bit 8 heating/cooling mode display Coding: 0 cooling mode Coding: 1 heating mode				
44	Status byte HVAC status	Status byte	2 byte DPT_HVAC Status	C, R, T
The communication object transfers the current state of the ambient temperature controller to the bus. The individual bits have the following meanings: Bit 0: comfort operation Bit 1: standby mode Bit 2: night mode Bit 3: frost/detection enabled Bit 4: dewpoint Bit 5: heating/cooling mode display Coding: 0 cooling mode Coding: 1 heating mode Bit 6: controller state Bit 7: frost alarm				

SATION KNX Commissioning

3.3.10 Compensation

Number	Name	Object Function	Length	C	R	W	T	U
45	Control	Summer compensation active	1 bit	C	R	-	T	-
46	Control	Winter compensation active	1 bit	C	R	-	T	-

No.	Function	Object name	Data type	Flags
45	Summer compensation active	Control	1 bit	C, R, T
<p>Summer compensation enabled is reported via this 1-bit communication object. This is always the case if the outside temperature exceeds the values specified in the summer compensation parameters.</p> <p>This data item forms the 1-bit KNX object and can be sent and received.</p> <p>0: summer compensation disabled 1: summer compensation enabled</p>				
46	Winter compensation active	Control	1 bit	C, R, T
<p>Winter compensation enabled is reported via this 1-bit communication object. This is always the case if the outside temperature falls below the values specified in the winter compensation parameters.</p> <p>This data item forms the 1-bit KNX object and can be sent and received.</p> <p>0: winter compensation disabled 1: winter compensation enabled</p>				

SATION KNX Commissioning

3.3.11 Fan stage - state

No.	Function	Object name	Data type	Flags
47	State stage 1	Fan coil operation state	1 Bit EIS1 DPT 1.001	C, W
This 1-bit communication object can be used by the ambient temperature controller to receive information about the status of the fan coil actuator. It can evaluate whether stage 1 or no stage was activated.				
48	State stage 2	Fan coil operation state	1 Bit EIS1 DPT 1.001	C, W
This 1-bit communication object can be used by the ambient temperature controller to receive information about the status of the fan coil actuator. It can evaluate whether stage 2 or no stage was activated.				
49	State stage 3	Fan coil operation state	1 Bit EIS1 DPT 1.001	C, W
This 1-bit communication object can be used by the ambient temperature controller to receive information about the status of the fan coil actuator. It can evaluate whether stage 3 or no stage was activated.				

SATION KNX Commissioning

3.3.12 Valve Heating / cooling

No.	Function	Object name	Data type	Flags
50	Trigger valve purge	Valve Heating	1 bit	C, W
<p>The valve purge is triggered using this communication object.</p> <p>Telegram value: 0 = end valve purge, valve will be closed 1 = start valve purge, valve will be opened</p> <p>Note for value 0: A purge currently underway is interrupted. The purge cycle with automatic purge will be restarted.</p>				
51	Status valve purge	Valve Heating	1 bit	C, R, T
<p>The status of the valve purge is visible via this communication object.</p> <p>Telegram value: 0 = valve purge not active 1 = valve purge active</p> <p>Note: The status is displayed as soon as a purge has been activated.</p>				
52	Trigger valve purge	Valve Cooling	1 bit	C, W
<p>The valve purge is triggered using this communication object.</p> <p>Telegram value: 0 = end valve purge, valve will be closed 1 = start valve purge, valve will be opened</p> <p>Note for value 0: A purge currently underway is interrupted. The purge cycle with automatic purge will be restarted.</p>				
No.	Function	Object name	Data type	Flags
53	Status valve purge	Valve Cooling	1 bit	C, R, T
<p>The status of the valve purge is visible via this communication object.</p> <p>Telegram value: 0 = valve purge not active 1 = valve purge active</p> <p>Note: The status is displayed as soon as a purge has been activated.</p>				

SATION KNX Commissioning

3.3.13 Function Buttons

No.	Function	Object name	Data type	Flags
54	Button : On/Off Button : Blind step/stop	Function Button	1 bit	C,W,T,U
Switch control: Parameter ON/OFF functions = ON / (ON, OFF or Toggle); Dimming control: On a short operation of the Top button: functions = ON; Blind control: On a short operation of the Top button: function = Step/Stop,sent value 0; On a short operation of the Bottom button: function = Step/Stop,sent value 1; When pressing the corresponding button, the corresponding telegram is sent immediately				
55	Button : On/Off Button : Blind up/down	Function Button	1 bit	C,W,T,U
Switch control: Parameter ON/OFF functions = OFF / (ON, OFF or Toggle); Dimming control: On a short operation of the Bottom button: functions = OFF; Blind control: On a short operation of the Top button: function = Step/Stop,sent value 0; On a short operation of the Bottom button: function = Step/Stop,sent value 1; When pressing the corresponding button, the corresponding telegram is sent immediately				
No.	Function	Object name	Data type	Flags
56	Button : Dim up/down	Function Button	4 bit DPT 3.007	C, R, T
When pressing the buttons longer, a dimming telegram is sent, e.g. press top button: "Brighter" is sent, press bottom button: "Darker" is sent. On releasing the button, a "Stop" telegram is sent.				
56	Button top : Scene	Function Button	1 Byte	C, R, T
57	Button bottom : Scene		DPT 18.001	
The "Scene (8-bit)" function is used to change the characteristics of a preset scene, i.e. brightness levels and switching states of a group within a scene, without using the ETS. For scene control, short and long (<1 s / > 5 s) pressing on the buttons are distinguished. On a short press, a telegram is sent to recall the corresponding scene. On a long press, a telegram is sent to save the corresponding scene. For each button a different scene number can be configured in ETS.				

3.4 Special operating states

Behaviour after reset

The behaviour after reset can be set for the operating mode, the operating type and the fan stage.

Heating, cooling and the state of the object "switching heating/cooling" can be selected for the operating mode. When it is set to "depending on object "switching heating/cooling"", the object state is queried via the bus when switching on or after a reset.

Comfort mode is default after reset, however Standby, Night mode or Frost/Heat Protection can also be selected.

The active fan stage after reset can be stage 1, 2 or 3. If no stage is to be active after reset, select the setting "Off". The setting "Automatic" switches on the fan stage in accordance with the current control value.

4 Planning and use

This section contains tips and application examples for practical application of the device.


4.1 Operating modes

The ambient temperature controller has the following four operating modes:

- Frost protection mode (with heating): ambient temperature control is disabled; heating is only on if the ambient temperature has fallen so far the heating system may be in danger of freezing.
Heat protection mode (with cooling): ambient temperature control is disabled; cooling is on only if the ambient temperature has risen so far that it is virtually impossible to use the room.
- Comfort mode (heating and cooling): the setpoint for the ambient temperature is set to a value that enables "normal usage" of the area at a pleasant temperature.
- Standby mode (heating): the ambient temperature is reduced (e.g. during temporary absence) to save heating costs but the comfort temperature can be restored quickly when necessary.
Standby mode (cooling): the ambient temperature is increased (e.g. during temporary absence) to save energy costs but the comfort temperature can be restored quickly when necessary.
- Night mode (heating and cooling): during the night areas are not used for extended periods; the ambient temperature is reduced to a value appropriate for the night and the comfort setpoint can be restored relatively quickly in the morning.


For switching between the operating modes switching telegrams (parameter "operating mode switching": "1 bit (3x)") or 1-byte value telegrams (parameter "operating mode switching": "1 byte (2x)") are used (see also drawings of operating modes on page 90, Section Operating mode switching).

4.1.1 Operating mode switching 1 bit



The frost/heat protection has the top priority, i.e. in this case switching to a different operating mode is disabled. Frost/heat protection must be disabled first, e.g. by closing an open window. Night mode has the next higher priority, followed by comfort mode. If none of the above three operating modes are enabled, the ambient temperature controller is in standby mode.

4.1.2 Operating mode switching 1 byte



When switching operating mode via 1 byte two 1-byte communication objects are available.

The two 1-byte communication objects have different behaviour when receiving a telegram. An object evaluates received telegrams as "normal" (operating mode switching). This means, for example, if a comfort telegram is received, the room thermostat switches to comfort mode. If a night telegram is received, the ambient temperature controller switches to night mode. This object is controlled, for example, by time switches.

The second object ("operating mode switching OMO") may "overwrite" the first temporarily. This means, for example, if a frost/heat protection telegram is received, the ambient temperature controller switches to frost or heat protection mode. If the frost or heat protection is reset by the receipt of another telegram, the ambient temperature controller enables the operating mode on the "normal" object. As a result, it is capable of noting operating modes. This object is controlled, for example, by binary inputs that record information from window contacts.

The following apply to both 1-byte communication objects:

- 0 = auto ("operating mode switching OMO" only)
- 1 = comfort
- 2 = standby
- 3 = night
- 4 = frost/heat protection
- 5 – 255 = not permitted

4.2 Temperature measurement

The ambient temperature controller with display can record the temperature with an internal sensor. Values can also be received from an external sensor or an outside temperature sensor via communication objects. Receipt of the values can be monitored and possibly calibrated. The functions are explained in more detail below.

4.2.1 Internal temperature recording

The device has an internal temperature sensor. The measured value is sent to the controller as a current value. The value is also shown on the display at the same time ("display in normal operation": "current actual value").

The measured temperature can also be sent over the bus with the 2-byte communication object "send current value - temperature sensor" to, for example, display as a visualisation. The transmission is done depending on the parameter "send current value on change up" and "send current value cyclically". Both parameters are disabled by default. This means that if the current temperature is to be sent, at least one setting must be enabled.

The setting "send current value on change up" has the advantage that even the smallest changes of the measured temperature, adjustable from 0.1 K to 1.0 K, are sent over the bus. The disadvantage is that, for example, the setting 0.1 K and a large number of ambient temperature controllers in one installation increases the bus load.

The parameter "send current value cyclically" has the advantage that the current value is sent continuously, even if the measured value does not change. The disadvantage is that fast changes may not be registered, because the cycle time has been set too large. However, it should also not be set too small to prevent excessive bus loading.

4.2.2 External temperature recording

In areas such as open plan offices it can be difficult to control the temperature with only a single ambient temperature controller. We recommend subdividing such areas into zones with additional temperature sensors.

The parameter "ambient temperature measurement" must be set to "internal" and "external" to enable the temperature value of the additional temperature sensor to be integrated. Then the internally and externally measured temperatures can also be weighted. The weighting settings depend on the local conditions. If the ambient temperature controller and the additional temperature sensor are equally distant from the radiators (flat radiators), the setting "50%/50%" should give good control results.

4.2.3 Monitoring

The "Monitoring temperature measurement" parameter defines whether the internal and external temperature sensors are to be monitored. This means that the ambient temperature controller must receive at least one telegram with the current temperature on the associated communication object within a configurable time ("monitoring time for external temperature" and "monitoring time for outside temperature").

If a telegram is not received within the monitoring time, the ambient temperature controller will assume that the sensor for the outside temperature or external temperature is faulty or no longer connected to the bus.

The room temperature controller will stop controlling and will send a predefined control value ("control value for temperature measurement error") to prevent the room from overcooling or overheating. The control value is transmitted until the ambient temperature controller receives a temperature telegram over the bus again and the control is enabled again.

4.2.4 Adjustment

If the measured temperature is falsified, for example by the internal heat of the bus coupler, an "ambient temperature adjustment value" can be set.

If an additional external temperature sensor has been enabled and the measured value is falsified by cold or heat influences, an adjustment value can also be set.

4.3 Controller

The ambient temperature controller can be used for heating only, cooling only or for heating and cooling.

If the ambient temperature controller is to be used for heating and cooling, it can switch automatically from heating to cooling and cooling to heating. The controller automatically detects whether it must send a control value for heating or cooling. If automatic switching is not wanted, switching between heating and cooling can be done by an external, central controller using the 1-bit object "switchover heating/cooling". In this setup, the heat and cooling icons are continuously displayed in the respective mode. The object is enabled by the parameter "switching between heating and cooling".

The control value that is sent for heating and/or cooling can be sent on a common communication object "control value heating/cooling" or two separate communication objects "control value heating" or "control value cooling". If a common object is used, it may be necessary to inform the actuator whether the control value refers to heating or cooling. The parameter "switchover between heating and cooling" can be enabled with the setting "automatic and send" a 1-bit communication object "switchover heating/cooling". If heating operating mode is enabled, a "1" is sent to the bus and if cooling operating mode is enabled, a "0" is sent.

A common communication object for heating and cooling is required to actuate 2-pipe systems, i.e. heating and cooling modes use the same pipes. Two single communication objects are used in 4-pipe systems, which have separate pipes for heating and cooling.


The parameter "number of output channels" defines whether an object ("1 channel (2-pipe system) for heating and cooling") or two objects ("2 channels (4-pipe system) for heating and cooling") are to be shown.

Separate control types can be parameterised for heating and cooling. One of the following control types can be selected:

- 2-point
- PWM
- continuous
- Fan Coil

The individual control types are described below in more detail.

4.3.1 2-point controller




A 2-point controller has two output states, which switch depending on the current value. If the current value is above the parameterised setpoint (22 °C at 21 °C setpoint), the control value "0" is sent to the bus. If the current value is below the parameterised setpoint (20 °C at 21 °C), the control value "1" is sent.

A 2-point controller is recommended if the control value is only required to switch between the two states ON and OFF, such as an electrothermal valve connected to a switching actuator. A 2-point controller can deal with control deviations with large changes of the command variables, but never comes to rest.

2-point controllers always have an integrated hysteresis, which varies around the setpoint, to prevent fast oscillations of the output states. The hysteresis can be parameterised in different magnitudes. For example, if the setpoint in heating mode is 21 °C and the hysteresis is 1.0 K, the controller switches on if the temperature falls below 20.5 °C and off if it exceeds 21.5 °C. The "hysteresis" parameter depends on how fast the heating can heat up the room and how fast the cooling can cool the room and also on the sensitivity to temperature of the people in the room. The hysteresis should not be set too small, because a switching actuator will be continuously opening and closing. The hysteresis must also not be too great, because the temperature variations in the room will be too large.

4.3.2 Continuous controller




A continuous controller has a continuously changing control value, which can take values between 0 and 100%. With the KNX the control value signal is converted to a 1-byte value, i.e. the control value of 0% corresponds to the value "0" and the control value 100% corresponds to the value "255".

Devices such as electromotor actuators can be controlled by a continuous controller with a 1-byte control value. They convert the received value directly to the valve position with an integrated motor. This enables optimum control.

The 1-byte control value of a continuous controller can also be sent to KNX heating actuators, which convert the 1-byte signal to a PWM value. This can be used to control electrothermal valves. It may be useful to restrict the dynamic range, because electrothermal valves required a certain time to open and close (see also page 98, Section 4.3.3 PWM controller). This is done with the parameters "minimum control value" and "maximum control value". For example, if a maximum control value of 80% is preset, the controller always automatically sends the value 255 if a control value of 204 is exceeded.

To prevent unnecessary bus loading the magnitude of the control value can be set to enable it to be sent on the bus. The setting is a percentage value. The transmission of the control value is determined by a cycle time if it has not changed. The cycle time should be set too small (e.g. every 10 min).

4.3.3 PWM controller



The PWM controller has the same continuous control as a continuous controller. The only difference is that with a PWM controller the 1-byte control value (0...255) is converted to a on/off ratio (0 and 1). For example, if a control value of 70% is output, the make time will be 7 minutes and the break time 3 minutes at a default cycle time of 10 minutes.

This transfers the advantages of continuous control (control to the desired setpoint, no oscillations) to drives that are designed for on/off signals only, such as electrothermal drives.

The "PWM control value cycle time" can be adjusted to optimise the control properties of the heating or cooling system. The type of heating or cooling and the actuator must be considered to set the cycle time appropriately. The following recommendations can be used:

a) electrothermal actuator

It takes 2-3 minutes to open an electrothermal valve fully.
A cycle time shorter than 15 minutes is therefore not reasonable.

b) underfloor heating

The time of constant of underfloor heating is very large.
A cycle time of 20 minutes is therefore sufficient.

c) hot-water heating

Electrothermal drives are commonly used. A cycle time of 15 minutes gives very good control results.

d) electrical convector heating

Cycle times between 10 and 15 minutes, depending on the electric heating and room conditions, are recommended.

4.3.4 Fan Coil

If fan coil is selected under "control types", the control values are output in the same way as described at continuous controllers.

A fan coil also has the option of controlling fan stages using a 1-byte or three 1-bit communication objects with a fan coil actuator.

Switching fan stages will heat or cool a room faster.


Stage limit in night mode	No limit
Automatic return from manual adjustment (0 - inactive, min)	0
Return inactive a fan stage off and automatic return not 0	☒ Yes ☐ No
Threshold value stage 1	10
Threshold value stage 2	40
Threshold value stage 3	70


The fan stage that is to be enabled at which control value is defined on a separate tab, "fan coil heating" or "fan coil cooling". Note that the threshold values must not overlap, i.e. the stage 1 threshold value must always be less than the stage 2 threshold value, which in turn must be less than the stage 3 threshold value.

4.3.5 Control parameters with PWM and continuous controller (fan coil)

With continuous control behaviour and switching PWM controllers the preset control parameters can be used via the installation type of the heating or air-conditioning system. If different parameters are required, they are set by free parameterisation. Free parameterisation should only be used if the user has sufficient experience in control technology.

The setting "free parameterisation" can be used to set the "proportional range (X_p)" and the "readjust time (T_n)". The proportional range is above and below the specified setpoint and determines the speed of the control. The readjust time is three times the delay time (the delay time is determined by the inflectional tangent of the heating curve of the room. With both settings the slower the overall system the greater the values required.





4.3.6 Two-stage heating and cooling

In specific instances such as when using underfloor heating, it may be necessary to install a quick additional stage for the heat control in order to warm up the room rapidly. When the room thermostat is pre-set to "supplementary-stage heating enabled", it has a second heating system with switching control (1-bit) or a "quasi-continuous" control, which is controlled with the 1-byte values 0% and 100%.

The parameters "gap of additional stage" and "Hysteresis (one-sided)" enable you to specify when the additional stage switches on and off. For example, if the setpoint is $18\text{ }^{\circ}\text{C}$ and the hysteresis 0.5 K (one-sided) for the additional stage, the controller switches on at $18\text{ }^{\circ}\text{C}$ and off at $18.5\text{ }^{\circ}\text{C}$.


The same settings as for the additional stage heating also apply for the additional stage cooling, except that for cooling an additional cooling stage is activated if an adjustable temperature is exceeded to cool the room faster.

Because some actuators close (open without power) at a 1-bit value of "1" or a 1-byte value of "255" and open at "0", the direction of the control value can be changed with "invert control value".

4.4 Setpoints

The ambient temperature controller can be operated with dependent or individual setpoints. The two options are explained in more detail below.

4.4.1 Dependent setpoints



Dependent setpoints have two base setpoints, one for heating ("heating setpoint comfort mode") and one for cooling ("cooling setpoint comfort mode").

The settings "...reduction standby/night mode" and "... reduction standby/night mode" refer to the base setpoint. This means that, for example, if "heating setpoint comfort mode" is set to 21 °C and 2 K has been set for "heating setpoint reduction standby", the heating setpoint is reduced 2 K to 19 °C in standby mode. If 4 K is specified for "heating setpoint reduction night mode", the heating setpoint in night mode is 17 °C.

The dependence of the setpoints is retained even after a manual setpoint adjustment. For example, if the user manually adjusts the setpoint of the specified temperature "heating setpoint comfort mode" up by 1 K to 22 °C, this value is reduced 2 K to 20 °C when standby mode is activated. In night mode the value is reduced by 4 K, making the setpoint 18 °C.


The user can manually change the parameterised setpoints with the two push-switches "increase temperature" and "reduce temperature". Push and hold the "increase temperature" push-switch (approx. 1 s) to switch between "heating setpoint comfort mode" and "cooling setpoint comfort mode" in the heating setpoint and the "reduce temperature" push-switch in the cooling setpoint.

The two setpoints for heating and cooling can be changed as much as desired over the bus, even without the ETS. A 2-byte temperature value must be sent to the communication object "base setpoint - control". The value is saved as "heating setpoint comfort mode" or "cooling setpoint comfort mode" depending on whether heating or cooling is currently enabled. The received values are written to the device memory and are retained even after a bus power failure and restoration. New base setpoints can also be sent to the device in the event of changes in room usage, such as by visualisation. A new parameterisation is not required.

The base setpoint reference is taken into account with a manual adjustment and dependent setpoints. This specifies whether the base setpoint refers to the comfort temperature for heating, cooling or the mid-range temperature between heat and cool.

"Setpoint heating" is the default setting. In regions where the cooling function is more important, it is recommended that you change this parameter to "Setpoint cooling". This makes it easier to set the ambient temperature controller and raise the cooling setpoints (standby temperature cooling and automatic night setback).

4.4.2 Individual setpoints



If individual setpoints are used, individual setpoints are parameterised for every operating mode ("heating setpoint comfort mode", "heating setpoint standby", "heating setpoint night mode", "cooling setpoint comfort mode", "cooling setpoint standby" and "cooling setpoint night mode").

In contrast to the dependent setpoints, the individual setpoints are retained even after a manual setpoint adjustment. For example, if the user manually adjusts the setpoint of the specified temperature "heating setpoint comfort mode" up or down, the parameterised value "heating setpoint standby" is always called when standby mode is enabled. This means that only the fixed setpoints for the individual operating modes are called.

The user can manually change the parameterised setpoints with the two push-switches "increase temperature" and "reduce temperature". Push and hold the "increase temperature" push-switch (approx. 1 s) to switch between "heating setpoint comfort mode" and "cooling setpoint comfort mode" in the heating setpoint and the "reduce temperature" push-switch in the cooling setpoint.

The parameterised setpoints can be changed as much as desired for any operating mode over the bus, even without the ETS. A 2-byte temperature value must be sent to the corresponding communication object "setpoint heating comfort", "setpoint heating standby", "setpoint heating night mode", "setpoint frost protection", "setpoint cooling comfort", "setpoint cooling standby", "setpoint cooling night mode" or "setpoint heat protection". The received values are written to the device memory and are retained even after a bus power failure and restoration. New setpoints can also be sent to the device in the event of changes in room usage, such as by visualisation. A new parameterisation is not required.

4.4.3 Minimum distance

The adjustable parameter "minimum distance between heating and cooling" is enabled with both dependent and individual setpoints.

The minimum distance is always between "heating setpoint comfort mode" and "cooling setpoint comfort mode". It acts as a buffer zone to prevent the two setpoints from overlapping.

Example:

Individual setpoints are selected. "Heating setpoint comfort mode" is set to 21 °C and "cooling setpoint comfort mode" is set to 26 °C. The dead zone between heating and cooling is 3 K. If the heating setpoint is moved up, the dead zone is also moved up. If the adjustment exceeds a temperature of 23 °C, "cooling setpoint comfort mode" is also adjusted up to ensure that there is always a minimum distance of 3 K between heating and cooling.

If the cooling setpoint is moved down, the dead zone is also moved down. If the adjustment exceeds a temperature of 24 °C, "heating setpoint comfort mode" is also adjusted down to ensure that the minimum distance is also retained in this case.

4.5 Fan Coil general

Ventilator convectors, also referred to as blower convectors or fan coil units, are used for decentralised heating and cooling. They are mounted in the room and supplied by a central heating and cooling system. A distinction is made between 2-pipe and 4-pipe systems (see also page 95, Section 4.3 Controller). A fan coil unit has multi-stage fans that enable fast adjustment of room temperature as required by the user. The Fan Coil ambient temperature controller with display can actuate up to three fan stages manually or automatically.

The fan stagers can be actuated in three ways:

- with 1-bit values,
i.e. a separate 1-bit communication object "fan coil stage ... switch" is available. This is required for "normal" switching actuators. (If KNX switching actuators and fan coil units are used, note the connection instructions of the fan coil unit.)
- with a 1-byte object as count value 0-3,
i.e. there is a 1-byte communication object "fan stage manual 1 byte", which is linked to a corresponding communication object of a fan coil actuator. Here the values are
0 = OFF
1 = stage 1
2 = stage 2
3 = stage 3
- with a 1-byte object as continuous value 0-100%,
i.e. there is a 1-byte communication object "fan stage manual 1 byte", which is linked to a corresponding communication object of a fan coil actuator. When a stage is manually switched, the stage fast values are transmitted, which are set on the heating or cooling tab. In heating mode the fast values for heating, in cooling mode the fast values for cooling. The parameters of the fan coil actuator must be appropriately configured to ensure that the fan coil unit also switches the fan stages.

The parameter "evaluate status byte fan stage" can be enabled by a 1-byte communication object "state fan coil operating state", which is linked to a corresponding object of a fan coil actuator. The fan coil ambient temperature controller is able to evaluate which fan stage in the fan coil actuator is actually enabled. The display shows the value of the communication object (0 = OFF, 1 = stage 1, 2 = stage 2, 3 = stage 3).

The parameter "status byte evaluate operation" enables a 1-bit communication object "receive in operation - actuator monitoring". Cyclic telegrams can be received and evaluated at this object by the fan coil actuator. This enables the ambient temperature controller to check that the fan coil actuator is still operating and can be actuated. If the fan coil actuator indicates a problem and cannot send cyclic telegrams, the ambient temperature controller indicates this by showing the "fault" symbol in the display. If the fault in the fan coil actuator is corrected and cyclic telegrams are being received again, the "fault" in the display disappears and the ambient temperature controller operates "normally" again.

When adjusting the cycle time "in operation" in the fan coil actuator, note that it must be at least twice as large as the monitoring time in the ambient temperature controller ("send cycle time of actuator in s"). A reasonable cycle time for the actuator is approx. 60 s with a monitoring time of 120 s in the ambient temperature controller.

For example, to prevent excessive noise during the night in hotel rooms, a "stage limitation in night mode" can be set. This means that only the specified fan stage or lower will be used in night mode. When switching to another operating mode all fan stages can still be used.

A limitation can be set to "stage 1" or "stage 2" or the fan can be completely disabled with the parameter "stage restriction in night mode".

4.6 Compensation

The fan coil ambient temperature controller with display has summer compensation and winter compensation modes. Both are explained in detail below.

4.6.1 Summer compensation

To save energy and to maintain the temperature differential when entering an air-conditioned building, you should adjust the room temperature in relation to the external temperature in summer (summer compensation in accordance with DIN 1946). The ambient temperature is increased by adjusting "cooling setpoint comfort mode".

Raising the room temperature does not, however, mean that you heat up the room. Rather the adjustment is intended to allow the room temperature without cooling to increase to a specified value. This prevents an air-conditioner from continuing to try to reduce the ambient temperature to 24 °C at an outside temperature of 35 °C.

However, an external temperature sensor that sends its measured values to the KNX and therefore can be evaluated by the ambient temperature controller with display is required to enable summer compensation.

The following parameters are available for summer compensation

- "summer compensation at lower outside temperature",
- "summer compensation at higher outside temperature",
- "summer compensation at lower setpoint offset" and
- "Summer compensation at upper setpoint offset".

The lower and upper outside temperature value specifies from and up to which temperature a setpoint should be corrected.

The lower and upper setpoint offset specifies how many K the setpoint should be adjusted during summer compensation in the parameters or by the user.


Typical values for summer compensation are

- 20 °C: lower outside temperature
- 32 °C: upper outside temperature
- 0 K: lower setpoint offset
- 4 K: upper setpoint offset

This means that a floating setpoint increase from 0 to 4 K will be implemented if the outside temperature increases from 20 °C to 32 °C.

Example:

Parameters for "cooling setpoint comfort" 25 °C are defined in the bottom graph. With rising outside temperature the parameterised setpoint is adjusted from an outside temperature of 20 °C from 25 °C to 29 °C. The 29 °C is reached at an outside temperature of 32 °C. From there the setpoint is no longer increased as the outside temperature continues to rise.



Note:

CO is shown in the display of the ambient temperature controller with active compensation.

4.6.2 Winter compensation

To improve comfort and to maintain a reasonable temperature differential when entering a room with a large window area, you should increase the room temperature depending on the outside temperature in winter (winter compensation). The ambient temperature is increased by adjusting "heating setpoint comfort mode".

Similarly to summer compensation, an external temperature sensor that sends its measured values to the KNX and therefore can be evaluated by the ambient temperature controller with display is required to enable winter compensation.

The following parameters are available for winter compensation

- "winter compensation lower temperature",
- "winter compensation upper outside temperature",
- "winter compensation lower setpoint offset" and
- "winter compensation upper setpoint offset".

The lower and upper outside temperature value specifies from and up to which temperature a setpoint should be corrected.

The lower and upper setpoint offset specifies how many K the setpoint should be adjusted during winter compensation in the parameters or by the user.


Typical values for winter compensation are

- 0 °C: lower outside temperature
- 10 °C: upper outside temperature
- 4 K: lower setpoint offset
- 0 K: upper setpoint offset

This means that a floating setpoint increase from 0 to 4 K will be implemented if the outside temperature falls from 10 °C to 0 °C.

Example:

Parameters for "heating setpoint comfort" 21 °C are defined in the bottom graph. With falling outside temperature the parameterised setpoint is adjusted from an outside temperature of 10 °C from 21 °C to 25 °C. The 25 °C is reached at an outside temperature of 0 °C. From there the setpoint is no longer increased as the outside temperature continues to fall.



Note:

CO is shown in the display when compensation is enabled.

Contact us

ZHUHAI SATION TECHNOLOGY CO.LTD.

BlogB1, No.1 Software Road, Zhuhai Hi-tech Zone, Guangdong, China

www.sation.com.cn

Tel: +86(0756)-3628187/287/387 Fax: +86(0756)-2612730